INSTALLATION INSTRUCTIONS Air Conditioner



This air conditioner uses the refrigerant R32.

Model No.

	Indoor Units			
T	Rated Capacity	36 - 50	60 - 71	100 - 140
Type	Indoor Units Type	3650	6071	1014
F3	Middle Static Pressure Duct	S-3650PF3E	S-6071PF3E	S-1014PF3E



ENGLISH

Read through the Installation Instructions before you proceed with the installation. In particular, you will need to read under the "IMPORTANT!" section at the top of the page.

IMPORTANT! Please Read Before Starting


This air conditioner must be installed by the sales dealer or installer.

This information is provided for use only by authorized persons.

For safe installation and trouble-free operation, you must:

- This Installation Instructions is for the indoor unit and read the Installation Instructions of the outdoor unit as well.
- Carefully read this instruction booklet before beginning.
- This air conditioner is required to have the remote controller which is adaptable to nanoe™ X function.
- Follow each installation or repair step exactly as shown.
- This air conditioner shall be installed in accordance with National Wiring Regulations.
- That compliance with national gas regulations shall be observed.
- The product meets the technical requirements of EN/IEC 61000-3-3.

 Pay close attention to all warning and caution notices given in this manual.



This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.

If Necessary, Get Help

These instructions are all you need for most installation sites and maintenance conditions. If you require help for a special problem, contact our sales/service outlet or your certified dealer for additional instructions.

In Case of Improper Installation

The manufacturer shall in no way be responsible for improper installation or maintenance service, including failure to follow the instructions in this document.



WARNING

- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater).
- Auxiliary devices which may be a **potential ignition source** shall not be installed in the duct work. Examples of such **potential ignition sources** are hot surfaces with a temperature exceeding 700°C and electric switching devices.
- For appliances connected via an air duct system to one or more rooms, only auxiliary devices approved by the appliance manufacturer or declared suitable with the refrigerant shall be installed in connecting ductwork.
- Do not pierce or burn.
- Be aware that refrigerants may not contain an odour.
- The following checks shall be applied to installations using flammable refrigerants. Appliance shall be installed, operated and stored in a room with a floor area larger than [Amin] m².

As for [Amin], see Section "12. CHECK OF DENSITY LIMIT".

SPECIAL PRECAUTIONS



WARNING When Wiring



ELECTRICAL SHOCK CAN CAUSE SEVERE PERSONAL INJURY OR DEATH. ONLY A QUALIFIED, EXPERIENCED ELECTRICIAN SHOULD ATTEMPT TO WIRE THIS SYSTEM.

 Do not supply power to the unit until all wiring and tubing are completed or reconnected and checked.

- Highly dangerous electrical voltages are used in this system. Carefully refer to the wiring diagram and these instructions when wiring. Improper connections and inadequate grounding can cause **accidental injury or death.**
- Connect all wiring tightly. Loose wiring may cause overheating at connection points and a possible fire hazard.
- Provide a power outlet to be used exclusively for each unit.
- Provide a power outlet exclusively for each unit, and full disconnection means having a contact separation by 3 mm in all poles must be incorporated in the fixed wiring in accordance with the wiring rules.
- To prevent possible hazards from insulation failure, the unit must be grounded.
- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects.
 The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.
- This equipment is strongly recommended to be installed with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD). Otherwise, it may cause electrical shock and fire in case of equipment breakdown or insulation breakdown.

When Transporting

- It may need two or more people to carry out the installation work.
- Be careful when picking up and moving the indoor and outdoor units. Get a partner to help, and bend your knees when lifting to reduce strain on your back. Sharp edges or thin aluminum fins on the air conditioner can cut your fingers.

When Storing...



WARNING

- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
- The appliance shall be stored in a room without continuously operating open flames (for example: an operating gas appliance) and ignition sources (for example: an operating electric heater).
- The appliance shall be stored so as to prevent mechanical damage from occurring.

When Installing...

- Select an installation location which is rigid and strong enough to support or hold the unit, and select a location for easy maintenance.
- In cases that require mechanical ventilation, ventilation openings shall be kept clear of obstruction.
- An unventilated area where the appliance using flammable refrigerants is installed shall be so constructed that should any refrigerant leak, it will not stagnate so as to create a fire or explosion hazard.
- Ducts connected to an appliance shall not contain a potential ignition source;
- For appliances connected via an air duct system to one or more rooms, the supply and return air shall be directly ducted to the space.
- Make sure to install protective guards on the suction and discharge side to prevent somebody from touching the fan motor, fan blades or heat exchanger.

...In a Room

Properly insulate any tubing run inside a room to prevent "sweating" that can cause dripping and water damage to walls and floors.

CAUTION Keep the fire alarm and the air outlet at least 1.5 m away from the unit.

...In Moist or Uneven Locations

Use a raised concrete pad or concrete blocks to provide a solid, level foundation for the outdoor unit. This prevents water damage and abnormal vibration.

...In an Area with High Winds

Securely anchor the outdoor unit down with bolts and a metal frame. Provide a suitable air baffle.

...In a Snowy Area (for Heat Pump-type Systems)

Install the outdoor unit on a raised platform that is higher than drifting snow. Provide snow vents.

...At Least 1.8 m (Horizontal Installation)

Installation height for indoor unit shall be at least 1.8 m.

...In Laundry Rooms

Do not install in laundry rooms. Indoor unit is not drip proof.

When Connecting Refrigerant Tubing

Pay particular attention to refrigerant leakages.



WARNING

- When performing piping work, do not mix air except for specified refrigerant in refrigeration cycle. It causes capacity down, and risk of explosion and injury due to high tension inside the refrigerant cycle.
- If the refrigerant comes in contact with a flame, it produces toxic gases and fire.
- Do not add or replace refrigerant other than specified type. It may cause product damage, burst and injury, etc.
- Ventilate the room immediately in the event of a refrigerant gas leakage during installation. Be careful not to allow contact of the refrigerant gas with a flame as this will cause the generation of toxic gases and fire.
- Keep all tubing runs as short as possible.
- Use the flare method for connecting tubing.
- Apply refrigerant lubricant to the matching surfaces of the flare and union tubes before connecting them, then tighten the nut with a torque wrench for a leak-free connection.
- Check carefully for leaks before starting the test run.
- Do not leak refrigerant while piping work for an installation or re-installation, and while repairing refrigeration parts.
 - Handle liquid refrigerant carefully as it may cause frostbite.
- Under no circumstances shall potential sources of ignition be used in the searching or detection of refrigerant leaks.
- A halide torch (or any other detector using a naked flame) shall not be used.
- Electronic leak detectors may be used to detect refrigerant leaks but, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.)
- Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.
- Leak detection equipment shall be set at a percentage of the Lower Flammable Limit (LFL) of the refrigerant and shall be calibrated to the refrigerant employed and the appropriate percentage of gas (25% maximum) is confirmed.

- Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.
- If a leak is suspected, all naked flames shall be removed/extinguished.
- If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. Oxygen Free Nitrogen (OFN) shall then be purged through the system both before and during the brazing process.

When Servicing

- Contact the sales dealer or service dealer for a repair.
- Be sure to turn off the power before servicing.
- Turn the power OFF at the main power box (mains), wait at least 5 minutes until it is discharged, then open the unit to check or repair electrical parts and wiring.



- Keep your fingers and clothing away from any moving parts.
- Clean up the site after you finish, remembering to check that no metal scraps or bits of wiring have been left inside the unit.



WARNING

- This product must not be modified or disassembled under any circumstances. Modified or disassembled unit may cause fire, electric shock or injury.
- Do not clean inside the indoor and outdoor units by users. Engage authorized dealer or specialist for cleaning.
- In case of malfunction of this appliance, do not repair by yourself. Contact the sales dealer or service dealer for a repair and disposal.



∕I∖ CAUTION

- Ventilate any enclosed areas when installing or testing the refrigeration system.
 Leaked refrigerant gas, on contact with fire or heat, can produce dangerously toxic gases.
- Confirm after installation that no refrigerant gas is leaking. If the gas comes in contact with a burning stove, gas water heater, electric room heater or other heat source, it can cause the generation of toxic gases and fire.

Others

When disposing of the product, do follow the precautions referring to Section "Recovery" in the installation instructions supplied with the outdoor unit and comply with national regulations.



WARNING

• Do not sit or step on the unit. You may fall down accidentally.





∕I∖ CAUTION

• Do not touch the air inlet or the sharp aluminum fins of the outdoor unit. You may get injured.



• Do not stick any object into the FAN CASE. You may be injured and the unit may be damaged.



SERVICING



- Any qualified person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognised assessment specification.
- Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- Servicing shall be performed only as recommended by the manufacturer.
- Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimised. For repair to the refrigerating system, (2) to (6) shall be completed prior to conducting work on the system.
- (1) Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapour being present while the work is being performed.
- (2) All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided. The area around the workspace shall be sectioned off. Ensure that the conditions within the area have been made safe by control of flammable material.
- (3) The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.
- (4) If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.
- (5) No person carrying out work in relation to a refrigerating system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
- (6) Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- (7) Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.
 - The actual refrigerant charge is in accordance with the room size within which the refrigerant containing parts are installed.
 - The ventilation machinery and outlets are operating adequately and are not obstructed.

- Marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected.
- Refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.
- (8) Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised. Initial safety checks shall include:
 - That capacitors are discharged. This shall be done in a safe manner to avoid possibility of sparking.
 - That no live electrical components and wiring are exposed while charging, recovering or purging the system.
 - That there is continuity of earth bonding.
- During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc.
- Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
- Ensure that apparatus is mounted securely.
- Ensure that seals or sealing materials have not degraded such that they no longer serve the purpose of preventing the ingress of flammable atmospheres.
- Replacement parts shall be in accordance with the manufacturer's specifications.

NOTE:

The use of silicon sealant may inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.

- Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use.
- Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere.
- The test apparatus shall be at the correct rating.
- Replace components only with parts specified by the manufacturer. Unspecified parts by manufacturer may result ignition of refrigerant in the atmosphere from a leak.

REMOVAL AND EVACUATION



• When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used.

However, it is important that best practice is followed since flammability is a consideration.

The following procedure shall be adhered to:

- Remove refrigerant.
- Purge the circuit with inert gas.
- Evacuate.
- · Purge again with inert gas.
- Open the circuit by cutting or brazing.
- The refrigerant charge shall be recovered into the correct recovery cylinders.
- The system shall be "flushed" with Oxygen Free Nitrogen (OFN) to render the unit safe.
- This process may need to be repeated several times.
- Compressed air or oxygen shall not be used for this task.
- Flushing shall be achieved by breaking the vacuum in the system with OFN and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.
- This process shall be repeated until no refrigerant is within the system.
- When the final OFN charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.
- This operation is absolutely vital if brazing operations on the pipe work are to take place.
- Ensure that the outlet for the vacuum pump is not close to any potential ignition sources and there is ventilation available.

CHARGING PROCEDURES

NOTE:

Refer to the Installation Instructions attached to the outdoor unit.

DECOMMISSIONING



T\ CAUTION

- Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its details.
- It is recommended good practice that all refrigerants are recovered safely.
- Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant.
- It is essential that electrical power is available before the task is commenced.
 - a) Become familiar with the equipment and its operation.
 - b) Isolate system electrically.
 - c) Before attempting the procedure ensure that:
 - Mechanical handling equipment is available, if required, for handling refrigerant cylinders.
 - All personal protective equipment is available and being used correctly.

- The recovery process is supervised at all times by a competent person.
- Recovery equipment and cylinders conform to the appropriate standards.
- d) Pump down refrigerant system, if possible.
- e) If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- f) Make sure that cylinder is situated on the scales before recovery takes place.
- g) Start the recovery machine and operate in accordance with instructions.
- h) Do not overfill cylinders. (No more than 80% volume liquid charge).
- i) Do not exceed the maximum working pressure of the cylinder, even temporarily.
- j) When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- k) Recovered refrigerant shall not be charged into another refrigerating system unless it has been cleaned and checked.
- Electrostatic charge may accumulate and create a hazardous condition when charging or discharging the refrigerant.
 - To avoid fire or explosion, dissipate static electricity during transfer by grounding and bonding containers and equipment before charging / discharging.

RECOVERY

NOTE:

Refer to the Installation Instructions attached to the outdoor unit.

NOTICE

The English text is the original instructions. Other languages are translations of the original instructions.

CONTENTS

	Page	Page
	PORTANT	8. TEST RUN
1.	GENERAL	 8-2. Test Run Procedure 8-3. Items to Check Before the Test Run 8-4. Check the Combination (wiring) of Indoor and Outdoor Units 8-5. Address Setting: 2-LINE CONNECTION 8-6. Address Setting: 3-LINE CONNECTION 8-7. Auto Address Setting Using the Remote Controller 8-8. How to Set Refrigerant System Address
2.	SELECTING THE INSTALLATION SITE	(Only outdoor PZ2 and PZH2 series) 8-9. Checking the Indoor Unit Addresses 8-10. Test Run Using the Remote Controller
3.	HOW TO INSTALL THE INDOOR UNIT15	8-11. Main-Sub Remote Controller Control9. CHECKLIST AFTER INSTALLATION
	 3-1. Required Minimum Space for Installation and Maintenance Services 3-2 Preparation Before Installation 3-3. Fix the Indoor Unit 3-4. Installing the Drain Pipe 3-5. Checking the Drainage 3-6. Connecting Duct to Air Intake Port Side 	WORK
4.	ELECTRICAL WIRING	 10-3. Operating the Timer Remote Controller (CZ-RTC4) 10-4. Operating the Wired Remote Controller (CZ-RTC6 series) 11. APPENDIX
5.	 HOW TO PROCESS TUBING 45 5-1. Connecting the Refrigerant Tubing 5-2. Connecting Tubing Between Indoor and Outdoor Units 5-3. Insulating the Refrigerant Tubing 5-4. Taping the Tubes 5-5. Finishing the Installation 	 Troubleshooting Tips for Energy Saving Important Information Regarding The Refrigerant Used
6.	HOW TO INSTALL THE TIMER REMOTE CONTROLLER OR HIGH-SPEC WIRED REMOTE CONTROLLER (OPTIONAL PART)	the outdoor unit. 12. CHECK OF DENSITY LIMIT
7.	HOW TO INSTALL WIRELESS REMOTE CONTROLLER	

1. GENERAL

This booklet briefly outlines where and how to install the air conditioning system. Please read over the entire set of instructions for the indoor and outdoor units and make sure all accessory parts listed are with the system before beginning.

The installation of pipe-work shall be kept to a minimum.

	WARNING	This symbol shows that this equipment uses a flammable refrigerant. If the refrigerant is leaked, together with an external ignition source, there is a possibility of ignition.
PLANIAGEE OAS	CAUTION	This symbol shows type of flammable refrigerant contained in the system.
	CAUTION	This symbol shows that the Operating Instructions should be read carefully.
	CAUTION	This symbol shows that a service personnel should be handling this equipment with reference to the Technical Manual.
	CAUTION	This symbol shows that there is information included in the Operating Instructions and/or Installation Instructions.

1-1. Tools Required for Installation (not supplied)

- 1. Flathead screwdriver
- 2. Phillips head screwdriver
- 3. Knife or wire stripper
- 4. Tape measure
- 5. Carpenter's level
- 6. Sabre saw or keyhole saw
- 7. Hacksaw
- 8. Core bits
- 9. Hammer
- 10. Drill
- 11. Tube cutter
- 12. Tube flaring tool
- 13. Torque wrench
- 14. Adjustable wrench
- 15. Reamer (for deburring)

1-2. Accessories Supplied with Unit

Part Name	Figure	Q'ty	Remarks
Washer	0))) 0)))	8	For suspending indoor unit from ceiling
Flare insulator		2	For gas and liquid tubes
Insulating tape		2	For gas and liquid tubes flare nuts
Drain insulator		1	For drain hose joint
Hose band	8	1	For securing drain hose
Packing		2	For drain hose joint (hard material)
Clamper	•	2	For drain hose joint
Drain hose		1	For main unit + PVC pipe joints
Clamper		2	For electrical wiring
Filter		*	When not connecting the air intake, be sure to install the filter.
Screw	®	*	

* S-3650PF3E : 1 Q'ty S-6071PF3E : 2 Q'ty S-1014PF3E : 2 Q'ty

Part Name	Figure	Q'ty	Remarks
Operating Instructions		1	
Installation Instructions		1	
Short-circuit connection		1	For vertical installation (Located on the back of the electrical component box lid.)

As for S-6071PF3E, the following accessories are additionally provided.

Part Name	Figure	Q'ty	Remarks
Different- diameter-tube		1	Gas socket tube A : $\emptyset15.88 \rightarrow \emptyset12.7$
joint		1	Liquid socket tube B : $\emptyset 9.52 \rightarrow \emptyset 6.35$
Insulating tape	8	2	For gas and liquid tube flare nuts

- Use M10 for suspension bolts.
- Field supply for suspension bolts and nuts.

1-3. Type of Copper Tube and **Insulation Material**

If you wish to purchase these materials separately from a local source, you will need:

- Deoxidized annealed copper tube for refrigerant tubing.
- 2. Foamed polyethylene insulation for copper tubes as required to precise length of tubing. Wall thickness of the insulation should be not less than 8 mm.
- Use insulated copper wire for field wiring. Wire size varies with the total length of wiring. See Section "4. ELECTRICAL WIRING" for details.



/I\ CAUTION

Check local electrical codes and regulations before obtaining wire. Also, check any specified instructions or limitations.

1-4. Additional Materials Required for Installation

- 1. Refrigeration (armored) tape
- Insulated staples or clamps for connecting wire (See your local codes.)
- 3. Putty
- 4. Refrigeration tubing lubricant
- Clamps or saddles to secure refrigerant 5. tubing
- Scale for weighing 6.

2. SELECTING THE INSTALLATION SITE

2-1. Indoor Unit


AVOID:

- areas where leakage of flammable gas may be expected.
- places where large amounts of oil mist exist.
- direct sunlight.
- locations near heat sources which may affect the performance of the unit.
- locations where external air may enter the room directly. This may cause "condensation" on the air discharge ports, causing them to spray or drip water.
- locations where the remote controller will be splashed with water or affected by dampness or humidity.
- installing the remote controller behind curtains or furniture.
- locations where high-frequency emissions are generated.

DO:

- select an appropriate position from which every corner of the room can be uniformly cooled.
- select a location where the ceiling is strong enough to support the weight of the unit.
- make sure to install protective guards on the suction and discharge side to prevent somebody from touching the fan motor, fan blades or heat exchanger.
- select a location where tubing and drain pipe have the shortest run to the outdoor unit.
- allow room for operation and maintenance as well as unrestricted air flow around the unit.
- the limitation of the tubing length between the indoor and the outdoor units should be referred to the Installation Instructions of the outdoor unit.
- allow room for mounting the remote controller about 1m off the floor, in an area that is not in direct sunlight or in the flow of cool air from the indoor unit.


< Horizontal installation >



* It is necessary to make space for the cleaning as well as the maintenance of the drain pan and the heat exchanger. Do not put any obstacle not to cause obstructing maintenance or cleaning works. If the place where the ceiling material cannot be removed, make an opening section below the bottom surface of the indoor unit in order to take it out. If it is impossible to provide an opening, make space more than 300 mm between the indoor unit's bottom surface

< Vertical installation >

and the ceiling material.



Н

• Lower side air intake with duct : 300 mm

• Lower side air intake without duct : 200 mm

• Front side air intake: 150 mm

HOW TO INSTALL THE INDOOR UNIT


3-1. Required Minimum Space for Installation and Maintenance Services


- This air conditioner is usually installed above the ceiling or behind the wall so that the indoor unit and ducts are not visible. Only the air intake and air outlet ports are visible from below.
- The minimum space for installation and maintenance services is shown in the figure.

< Horizontal installation >

Min. 20

Unit: mm





Minimum space for installation and maintenance services

Unit: mm

Туре	3650	6071	1014
A (Length)	867	1,067	1,467


* It is necessary to make space for the cleaning as well as the maintenance of the drain pan and the heat exchanger.


Do not put any obstacle not to cause obstructing maintenance or cleaning works.

If the place where the ceiling material cannot be removed, make an opening section below the bottom surface of the indoor unit in order to take it out. If it is impossible to provide an opening, make space more than 300 mm between the indoor unit's bottom surface and the ceiling material.

Please install inspection door both edge of drain pan if you cannot service and maintenance under the unit.


< Vertical installation >






Unit: mm

- H Lower side air intake with duct : 300 mm
 - Lower side air intake without duct : 200 mm
 - Front side air intake : 150 mm
 - * Make it possible to open / close for maintenance services.






Unit: mm

- H Lower side air intake with duct : 300 mm
 - Lower side air intake without duct : 200 mm
 - Front side air intake: 150 mm
 - * Make it possible to open / close for maintenance services.
- It is recommended that space be provided (450 x 450 mm) for checking and servicing the electrical system.

Detailed dimensions of indoor unit

Type	Α	В	С	D	E	F
Туре	mm	mm	mm	mm	mm	Q'ty
3650	867	800	450 (Pitch 150 × 3)	71	592	12
6071	1,067	1,000	750 (Pitch 150 × 5)	21	792	16
1014	1,467	1,400	1,050 (Pitch 150 × 7)	71	1,192	20




Unit: mm

3-2. Preparation Before Installation

3-2-1. Main Types of Installation


Case A (Standard installation)

Horizontal installation in the ceiling, rear side air intake



Case C


Vertical installation on the sidewall, lower side air intake



* While in heating mode, the temperatures may increase higher than the set temperature.


Case B

Horizontal installation in the ceiling, lower side air intake



Case D

Vertical installation on the sidewall, front side air intake




Front side air intake

* While in heating mode, the temperatures may increase higher than the set temperature.

3-2-2. Install the Filter

When not connecting the air intake duct, be sure to install the filters (Accessories). Case A and Case C are shown below.




Attach the filters (accessories) in the manner shown in the figure. Securely fix the filters with the screws.

Case B and Case D are shown below.


For Case B and Case D, replace the cover plates in the procedure shown in the figure.

Type 3650

1. Remove the cover plates (2 pcs).




2. Attach the cover plates removed in Step 1 and filter (accessory) in the direction shown in the figure below.




Type 6071, 1014


1. Remove the cover plate and the support plate (Type 1014 only).



2. Attach the cover plate and the support plate removed in Step 1 and filters (accessories) in the direction shown in the figure below.



3. Attach the filters (accessories) in the manner shown in the figure. Securely fix the filters with the screws.




3-3. Fix the Indoor Unit


3-3-1. Horizontal Installation

Depending on the ceiling type:

- a) Insert suspension bolts or
- b) Use existing ceiling supports or construct a suitable support.



a)



b)




It is important that you use extreme care in supporting the indoor unit inside the ceiling. Ensure that the ceiling is strong enough to support the weight of the unit. Before hanging the unit, test the strength of each attached suspension bolt.


(1) When placing the unit inside the ceiling, determine the pitch of the suspension bolts referring to the dimensional data as shown in the tables and diagrams under Section 3-1.

Tubing must be laid and connected inside the ceiling when suspending the unit. If the ceiling is already constructed, lay the tubing into position for connection to the unit before placing the unit inside the ceiling.


(2) Screw in the suspension bolts allowing them to protrude from the ceiling. (Cut the ceiling material, if necessary.)

(3) Thread the 3 hexagonal nuts and 2 washers (field supply) onto each of the 4 suspension bolts. Use 1 nut and 1 washer for the upper part, and 2 nuts and 1 washer for the lower part, so that the unit will not fall off the suspension lugs.






This shows an example of installation.




 Check to make sure the unit is installed in a horizontal position by using a level.
 Water leakage may occur if the unit is not installed horizontally.

3-3-2. Vertical Installation

- To prevent overturning, fasten the unit to the wall securely.
- Check to make sure the wall and the bolts can endure 5 times of weight of the unit.
 Ensure to fix the unit.
- In order to suppress vibrations, provide the spacer between the unit and the wall.
- Fasten the hanging brackets and bolts using by the hexagon nuts and washers.
- Check to make sure the unit is installed in a horizontal position by using a level.
 Water leakage may occur if the unit is not installed horizontally.





3-4. Installing the Drain Pipe

 Prepare standard hard PVC pipe (O.D. 26 mm) for the drain and use the supplied hose band to prevent water leaks.


The PVC pipe must be purchased separately.

The transparent drain part on the unit allows you to check drainage.





CAUTION

- Do not use adhesive tape at the drain connection port on the indoor unit.
- Insert the drain pipe until it contacts the socket, and then secure it tightly with the hose band.
- Do not use the supplied drain hose bent at a 90° angle. (The maximum permissible bend is 45°.)
- Tighten the hose clamps so their locking nuts face upward.
- (2) Installing the drain hose
- First insert the drain hose (supplied) to the hose band (supplied) and then install the drain hose to the unit drain port.
- Insert until the drain hose bumps to the end.
- Hose band screw torque is 30 35 N · cm.
- Connect both the drain hose and PVC pipe (VP20 or similar material, not supplied). Insert until the PVC pipe bumps to the end and adhere with PVC adhesive.



(3) After connecting the drain pipe securely, wrap the supplied packing and drain pipe insulator around the pipe, then secure it with the clampers.





3-4-1. Horizontal Installation


NOTE

Make sure the drain pipe has a downward gradient (1/100 or more) and that there are no water traps.




CAUTION


 Do not install an air bleeder as this may cause water to spray from the drain pipe outlet.




 If it is necessary to increase the height of the drain pipe, the section directly after the connection port can be raised a maximum of 500 mm. Do not raise it any higher than 500 mm, as this could result in water leaks.



 Do not install the pipe with an upward gradient from the connection port.
 This will cause the drain water to flow backward and leak when the unit is not operating.




Do not apply force to the piping on the unit side when connecting the drain pipe. The pipe should not be allowed to hang unsupported from its connection to the unit. Fasten the pipe to a wall, frame, or other support as close to the unit as possible.




3-4-2. Vertical Installation

Replace the drain cap
 Remove the drain cap from the bottom
 drain port and reinstall it to the upper
 drain port.




The drain cap can be inserted easily by using a screwdriver or similar tool to push the drain cap into the drain port on the main unit. Push the drain cap into the main unit's drain port until it reaches the end-stop.




Replace the connectors

When installing the unit vertically, disconnect the connectors of the drain pump (3-pin) and the float switch (2-pin) from the PCB.



Insert the supplied short-circuit connection to the place where the connectors were removed.

Short-circuit connection (Accessories)




- * Pay attention to the type of connector.
- After switching on the power, invalidate the drain pump and change the heating intake temperature by setting the remote controller. (For details, see next page.)

How to make drain pump ineffective and changing heating intake temperature

Operating the High-spec Wired Remote Controller (CZ-RTC5B)


Stop the system before performing these steps.



After completing the address setting under Section "8. TEST RUN", carry out the following procedure.


Keep pressing the , and buttons simultaneously for 4 or more seconds.

The "Maintenance func" screen appears on the LCD display.




2. Press the ▼ or ▲ button to see each menu.


If you wish to see the next screen instantly, press the or button. Select "8. Detailed settings" on the LCD display and press the button.



The "Detailed settings" screen appears on the LCD display.

3. Select the "Unit no." by pressing the
or ▲ button for changes.






5. Select the "Set data" by pressing the

or ▶ button.

("0007" or "0000" set at shipment)

Change the Setting Data "0001" by pressing the ▼ or ▶ button.

Then press the ▶ button.



7. Select the "Set data" by pressing the

or ▶ button.

("0004" set at shipment)

Change the Setting Data "0000" by pressing the ▼ or ▶ button.

Then press the ▶ button.

8. Select the "Unit no." by pressing the or button and press the button.

The "Exit detailed settings and restart?" (Detailed setting-end) screen appears on the LCD display.


Select "YES" and press the ___ button.



Operating the Timer Remote Controller (CZ-RTC4)

Stop the system before performing these steps.

Setting Item Code "] and " [] and



- 1. Press and hold down the , and buttons simultaneously for 4 or more seconds.
 - (SETTING, the unit no., item code and detailed data will blink on the LCD display.)
- 2. The indoor unit numbers in the group control will be sequentially displayed whenever the Unit Select button is pressed ...
 - Only the fan motor for the selected indoor unit will operate during this time.

- 4. Press the \(\sum_{\cup}\)/\sum_\ buttons for the time to amend the values for the set data. Select "\(\begin{align*}[c]{0.5cm} \begin{align*}[c]{0.5cm} \begin{align*}[c
- 5. Press the button.
 The display will stop blinking and remain illuminated.
- 6. Specify the "☐☐" item code by pressing the ▽/△ buttons for the temperature setting buttons and confirm the values. ("☐☐☐☐☐" ☐☐" set at shipment)
- 7. Press the \(\sum_{\text{\texts}}^\text{\texts}\)/ \(\sum_{\text{\texts}}^\text{\text{\texts}}\) buttons for the time to amend the values for the set data. Select "\(\text{\texts}\) \(\text{\texts}\) \(\text{\texts}\)\(\text{\texts}\).
- 8. Press the button.
 The display will stop blinking and remain illuminated.
- 9. Press the putton to return to normal remote controller display.


^{*}Failure to make this setting may cause malfunction of the drain pump.

Operating the Wired Remote Controller (CZ-RTC6 series) Stop the system before performing these steps.

1. Keep pressing the ≡, △ and ➡ buttons simultaneously for 4 or more seconds.

The "Maintenance func" screen appears on the LCD display.





2. Press the ✓ or ✓ button to see each menu.
Select "Detailed settings" on the LCD display and press the button.

The "Detailed settings" screen appears on the LCD display.

3. Select the "Unit no." by pressing the ✓ or ✓ button.

After selecting "Unit no.", press the ✓ button and proceed to Step 4.

If the button is pressed, proceed to Step 8.

4. Keep pressing the button for 2 seconds or more during selecting "Code no.".

Change the "Code no." one digit at a time so that it becomes [00003F] along with the following procedures.

Change the value by pressing the or button.

After changing the value, press the button and set the next digit.

Change the value by pressing the or button.

After changing the value, press the button and set the next digit.

Change the value by pressing the ✓ or △ button.

After changing all digits, press the ✓ button and proceed to Step 5.

("0007" or "0000" set at shipment)















5. Select one of the Setting Data "0001" by pressing the ✓ or △ button.

After selecting "Set data", press the — button.



6. Keep pressing the button for 2 seconds or more during selecting "Code no.".

Change the "Code no." one digit at a time so that it becomes [000006] along with the following procedures.

Change the value by pressing the ✓ or △ button.

After changing the value, press the ✓ button and set the next digit.

Change the value by pressing the value, press the button and set the next digit.

Change the value by pressing the ✓ or ⋀ button.

After changing all digits, press the ✓ button and proceed to Step 5.

("0004" set at shipment)

7. Select one of the Setting Data "0000" by pressing the ✓ or △ button.

After selecting "Set data", press the button. If you wish to change the selected indoor unit or finish setting, press the button twice (the display returns to Step 3).


8. If the button is pressed under the display Step 3, the following display (Detailed setting-end screen) appears.

Then select "YES" by pressing the ✓ or ✓ button and press the ✓ button.

(Return to normal remote controller display.)
















NOTE


Make sure the drain pipe has a downward gradient (1/100 or more) and that there are no water traps.



CAUTION

 Do not install an air bleeder as this may cause water to spray from the drain pipe outlet.





- (1) Drain hose connection
- The drain hose is connected below the refrigerant tubing.




- Wrap the drain insulator (supplied) between the connection of the drain hose and tubing not to expose the copper tubing.
 - Also, wrap the hose band together. Wrap the hose band with the drain insulator, where the screw is located facing upward. Then, tighten the insulator with a vinyl tape not to cause the detachment.
 - If the tubing parts remain exposed, condensation may occur.
- Be sure to use the supplied drain hose.
- If other commercially available hose bands are used, the drain hose may become pinched or wrinkled and there is danger of water leakage. Therefore be sure to use the supplied hose bands.
- Connect the drain pipe so that it slopes downward from the unit to the outside.
- Never allow water traps to occur in the course of the piping.
- Insulate any piping inside the room to prevent dripping.
- After the drain piping, pour an appropriate amount of water into the drain pan through the opening on the side of the air discharge port. Check the water draining smoothly.

3-5. Checking the Drainage

3-5-1. Horizontal Installation Only

After wiring and drain piping are completed, use the following procedure to check that the water will drain smoothly. For this, prepare a bucket and wiping cloth to catch and wipe up spilled water.

- (1) Connect power to the power terminal board (L/1, N/2 terminals) inside the electrical component box.
- (2) Remove the tube cover and slowly pour about 1,200 cc of water through the opening into the drain pan to check drainage.
- (3) Short the check pin (CHK) (6P: 1-4) on the indoor unit control PCB and operate the drain pump. Check the water flow through the transparent upper drain port and see if there is any leakage.
 - * If the check pin (CHK) (6P: 1-4) is shorted, the fan starts rotating at high speed and could cause injury.
- (4) When the drainage check is complete, open the check pin (CHK) (6P: 1-4) and remount the insulator and the cap onto the drain inspection port.




Drain inspection port


3-6. Connecting Duct to Air Intake Port Side


(1) Install the duct (field supply).


See the figure for the dimension of the installation hole.

Use M4 self-tapping screws for installation.









NOTE

To get clean air and to extend the service life of the air conditioner, an air filter must be installed in the air intake.

For installation and cleaning the air filter, consult your dealer or service center.

4. ELECTRICAL WIRING

4-1. General Precautions on Wiring

(1) Before wiring, confirm the rated voltage of the unit as shown on its nameplate, then carry out the wiring closely following the wiring diagram under Section 4-3.

/ WARNING

- (2) This equipment is strongly recommended to be installed with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD). Otherwise, it may cause electrical shock and fire in case of equipment breakdown or insulation breakdown. The ELCB must be incorporated in the fixed wiring in accordance with the wiring regulations. The ELCB must be an approved circuit capacity, having a contact separation in all poles.
 - The ELCB or RCD suitable for use with inverters, resistant to high frequency noise, is most suitable. The ELCB's or RCD's intended for protection to include high frequency currents are unnecessary and should be avoided, as potentially causing nuisance tripping, in this application.
- (3) To prevent possible hazards from insulation failure, the unit must be grounded.
- (4) Each wiring connection must be done in accordance with the wiring system diagram. Wrong wiring may cause the unit to misoperate or become damaged.
- (5) Do not allow wiring to touch the refrigerant tubing, compressor, or any moving parts of the fan.
- (6) Unauthorized changes in the internal wiring can be very dangerous. The manufacturer will accept no responsibility for any damage or misoperation that occurs as a result of such unauthorized changes.
- (7) Regulations on wire diameters differ from locality to locality. For field wiring rules, please refer to your LOCAL ELECTRICAL CODES before beginning.
 - You must ensure that installation complies with all relevant rules and regulations.
- (8) To prevent malfunction of the air conditioner caused by electrical noise, care must be taken when wiring as follows:
 - The remote control wiring and the inter-unit control wiring should be wired apart from the inter-unit power wiring.
 - Use shielded wires for inter-unit control wiring between units and ground the shield on both sides.



Check local electrical codes and regulations before wiring. Also, check any specified instruction or limitations.

4-2. Wire Length and Wire Diameter for Power Supply System


Connection cable between outdoor and indoor unit has 2 types; One is 2-line connection and the other is 3-line connection. Check the type of the outdoor unit terminal board as illustrated below and make connection.

- If U1 and U2 are shown on the terminal board, it is for 2-line connection.
 - * See the example in Section 4-3.



Inter-unit (between outdoor and indoor units) control wiring

- If 1, 2 and 3 are shown on the terminal board, it is for 3-line connection.
 - * See the example in Section 4-3.



Power supply cable Connection cab between outdoor and indoor unit

Connection cable between outdoor



Connection cable between outdoor and indoor unit

Indoor unit

(Type of 2-line connection [U1, U2] with indoor and outdoor units)

Time	(B) Power supply cable	Time delay fuse or circuit capacity	
Туре	Min. 2.5 mm ² *1		
F3	Max. 90 m *3	15 A	

Indoor unit

(Type of 3-line connection [1, 2 and 3] with indoor and outdoor units)

Туре	(B) Power supply cable Min. 2.5 mm ² *1	Time delay fuse or circuit capacity	
F3	Max. 90 m*3	15 A	

	Connection cable between outdoor and indoor unit		
Туре	(F) Outdoor unit U-36, 50PZ3E5, U-60, 71PZ3E5A Min. 1.5 mm ² *1	(G) Outdoor unit U-100 ~ 140PZ3E5, U-100 ~ 140PZ3E8 Min. 2.5 mm ^{2 *1}	
F3	Max. 40 m *3	Max. 50 m *3	

	Connection cable between outdoor and indoor unit		
Туре	(F) Outdoor unit U-36 ~ 60PZH3E5 Min. 1.5 mm ^{2 *1}	(G) Outdoor unit U-71 ~ 140PZH3E5, U-71 ~ 140PZH3E8 Min. 2.5 mm ^{2 *1}	
F3	Max. 40 m *3	Max. 85 m *3	

Control wiring

(C) Inter-unit (between outdoor and indoor units) control wiring	(D) Remote control wiring	(E) Remote control wiring for group control
Min. 0.75 mm ² Use shielded wiring* ²	Min. 0.75 mm ²	Min. 0.75 mm ²
Max. 1,000 m	(D) + (E) : Max. 500 m (E) : Max. 200 m	
	The above descriptions can be used for the model CZ-RTC4, CZ-RTC5B or CZ-RTC6 series. For other remote controllers, refer to the manual of each unit.	

NOTE


^{*1} Maximum applicable wire for terminal board of indoor unit: 4 mm²

^{*2} With ring-type wire terminal


^{*3} Maximum length shows a 2% voltage drop.

4-3. Wiring System Diagrams

■ 2-LINE CONNECTION




Indoor unit wiring sample



^{*1} Fasten tightly.


■ 2-LINE CONNECTION

Example: Twin connection



(\(\phi : Functional earthing)


Indoor unit (No. 1) wiring sample




^{*1} Fasten tightly.

■ 3-LINE CONNECTION

Example: Single connection




Indoor unit wiring sample




^{*1} Fasten tightly.

■ 3-LINE CONNECTION

Example: Twin connection




Indoor unit (No. 1) wiring sample



^{*1} Fasten tightly.


■ 3-LINE CONNECTION




R2

Indoor unit (No. 1) wiring sample

Indoor unit (No. 2) wiring sample



After all of the wires are connected, close the lid of the electrical component box. Make the distance between two cables (1) and (2)) as shown in the figure to the right.




2 Inter-unit (between outdoor and indoor units) control wiring / Remote control wiring / Integrated control wiring


1) Power supply cable / Connection cable between outdoor and indoor unit

NOTE

- (1) See Section 4-2 for the explanation of "B", "C", "D", "E", "F" and "G" under Section 4-3.
- (2) The basic connection diagram of the indoor unit shows the terminal boards, so the terminal boards in your equipment may differ from the diagram.
- (3) Refrigerant Circuit address should be set before turning the power on.
- (4) Regarding Refrigerant Circuit address setting, refer to the installation instructions supplied with the remote controller (Optional). Auto address setting can be executed by remote controller automatically.



Inter-unit Remote control wiring wiring



and indoor unit


Type F3



- (1) When connecting to the integrated control system, the setting of the terminating resistance is required. Even more connection with the integrated control system is required, all indoor units in the link of 3-line connection should be connected with 2-line link wiring.
 - How to set the terminating resistance of the indoor unit
 The setting of the terminating resistance should be made by CN045 on the indoor unit control PCB.

The setting of indoor unit terminating resistance at shipment is OPEN side. If the shorting socket is moved as shown below, the terminating resistance is SHORT side (operative).


It is not necessary to install all units' terminating resistance. Follow the steps on the next page which unit's terminating resistance to install.




How to set the terminating resistance of the outdoor unit
 The setting of the terminating resistance should be made by CN-TERMINAL on the outdoor unit control PCB.

The setting of the outdoor unit terminating resistance at shipment is SHORT side (operative). Leave one unit in short circuit among outdoor units in the link. Change to OPEN for other units. It is not necessary to install all units' terminating resistance to OPEN side.


It is not necessary to install all units' terminating resistance. Follow the steps on the next page which unit's terminating resistance to install.



(2) Do not install the inter-unit control wiring in a way that forms a loop.




(3) Do not install inter-unit control wiring such as star branch wiring. Star branch wiring causes mis-address setting.




(4) If branching the inter-unit control wiring, the number of branch points should be 16 or fewer.

The setting of the terminating resistance changes according to the number of refrigerant systems connected to the integrated control wiring in the link.


- For one refrigerant system in the link wiring, it is necessary to set one terminating resistance to the valid (SHORT side). For over 2 refrigerant systems, it is necessary to set 2 terminating resistance to the valid (SHORT side).
- The valid or invalid setting of the terminating resistance is basically carried out with the outdoor unit. However, 3-line connection outdoor unit cannot make a setting of terminating resistance. In this case, the shortage of the valid setting for the terminating resistance should be carried out with the indoor unit. The setting of the terminating resistance of the 2-line outdoor unit at shipment is the valid (SHORT side) and indoor unit is the invalid (OPEN side).
- In case that the inter-unit control wiring in the link are all 3-line connection:




- In case that the inter-unit control wiring in the link are all 2-line connection only, or mixed with 2-line and 3-line connections:
 - 1) All refrigerant systems are 2-line connection:




2) Only one refrigerant system is 2-line connection and other refrigerant systems are 3-line connection:






3) Only one refrigerant system is 3-line connection and other refrigerant systems are 2-line connection:



(5) Use shielded wires for inter-unit control wiring (C) and ground the shield on both sides, otherwise misoperation from noise may occur. Connect wiring as shown in Section 4-3.



- (6) In the case of 3-line connection, connection cable between outdoor and indoor unit shall be approved polychloroprene sheathed flexible cord. Type designation 60245 IEC57 (H05RN-F, GP85PCP, etc.) or heavier cord.
 - Use the standard power supply cables for Europe (such as H05RN-F or H07RN-F which conform to CENELEC (HAR) rating specifications) or use the cables based on IEC standard. (60245 IEC57, 60245 IEC66)




Loose wiring may cause the terminal to overheat or result in unit malfunction. A fire hazard may also occur. Therefore, ensure that all wiring is tightly connected.

When connecting each power wire to the terminal, follow the instructions on "How to connect wiring to the terminal" and fasten the wire securely with the terminal screw.

How to connect wiring to the terminal

■ For stranded wiring

- (1) Cut the wire end with cutting pliers, then strip the insulation to expose the stranded wiring about 10 mm and tightly twist the wire ends. Then attach the ring pressure terminal.
- (2) Using a Phillips head screwdriver, remove the terminal screw(s) on the terminal board.
- (3) Using a ring connector fastener or pliers, securely clamp each stripped wire end with a ring pressure terminal.
- (4) Place the ring pressure terminal, and replace and tighten the removed terminal screw using a screwdriver.




Ring

Stranded wire

■ Examples of shield wires

- (1) Remove cable coat not to scratch braided shield.
- (2) Unbraid the braided shield carefully and twist the unbraided shield wires tightly together. Insulate the shield wires by covering them with an insulation tube or wrapping insulating tape around them.
- (3) Remove coat of signal wire.
- (4) Attach ring pressure terminals to the signal wires and the shield wires insulated in Step (2).



5. HOW TO PROCESS TUBING

Must ensure mechanical connections be accessible for maintenance purposes.

5-1. Connecting the Refrigerant Tubing

Use of the Flaring Method

Many of conventional split system air conditioners employ the flaring method to connect refrigerant tubes that run between indoor and outdoor units. In this method, the copper tubes are flared at each end and connected with flare nuts.

Flaring Procedure with a Flare Tool

- (1) Cut the copper tube to the required length with a tube cutter. It is recommended to cut approx. 30 50 cm longer than the tubing length you estimate.
- (2) Remove burrs at each end of the copper tubing with a tube reamer or a similar tool. This process is important and should be done carefully to make a good flare. Be sure to keep any contaminants (moisture, dirt, metal filings, etc.) from entering the tubing.



When reaming, hold the tube end downward and be sure that no copper scraps fall into the tube.

- (3) Remove the flare nut from the unit and be sure to mount it on the copper tube.
- (4) Make a flare at the end of the copper tube with a flare tool.


NOTE

When flared joints are reused, the flare part shall be re-fabricated. A good flare should have the following characteristics:

- inside surface is glossy and smooth
- edge is smooth
- tapered sides are of uniform length


Caution Before Connecting Tubes Tightly

- (1) Apply a sealing cap or water-proof tape to prevent dust or water from entering the tubes before they are used.
- (2) Be sure to apply refrigerant lubricant (ether oil) to the inside of the flare nut before making piping connections. This is effective for reducing gas leaks.
- (3) For proper connection, align the union tube and flare tube straight with each other, then screw on the flare nut lightly at first to obtain a smooth match.
- Adjust the shape of the liquid tube using a tube bender at the installation site and connect it to the liquid tubing side valve using a flare.




Reamer

Deburring







5-2. Connecting Tubing Between Indoor and Outdoor Units

(1) Tightly connect the indoor-side refrigerant tubing extended from the wall with the outdoor-side tubing.

Unit: mm

Indoor Unit Tubing Connection


Indoor unit type	S-3650PF3E	S-6071PF3E	S-1014PF3E			
Gas tube	ø12.7	ø15.88 (ø12.7)	ø15.88			
Liquid tube	ø6.35	ø9.52 (ø6.35)	ø9.52			

Different-diameter-tube joint for the indoor unit tubing connection part is supplied with S-6071PF3E.


The size of parenthesis indicates the connection tube diameter when using the different-diameter-tube joint.

How to use different-diameter-tube joint (supplied)

- 1) When using with single connection
 - Outdoor PZ3 series (Type 60)



• Outdoor PZ3 series (Type 71)



The outdoor PZ2 and PZH2 series do not use the different-diameter-tube joint.

The following examples show the multiple connections.

- Connectable or disconnectable units vary depending on a series of outdoor units. Refer to the installation instructions for the outdoor unit as well.
- Two, three or four indoor units can be operated simultaneously with a single remote controller. Note that individual operation is not possible.
- Master unit and slave unit can be set automatically in twin, triple and double twin system.
 No address setting is necessary.

Applicable "TWIN", "TRIPLE" and "DOUBLE TWIN" combination table

	Outdoor unit	Type 71 (Only PZH series)	Type 100	Type 125
TWIN	combination	U-71 (S-3650) (S-3650)	(U-100) (S-3650) (S-3650)	(U-125) (S-6071) (S-6071)
TRIPLE	combination		(U-100) (S-3650) (S-3650) (S-3650)	(J-125) (S-3650) (S-3650) (S-3650)
DOUBLE	combination			(U-125) (S-3650) (S-3650) (S-3650)
	Outdoor unit	Type 140		
NIWT	combination	(J-140) (S-6071) (S-6071)		
TRIPLE	combination	(J-140) (S-3650) (S-3650) (S-3650)		
DOUBLE	combination			

- (2) To fasten the flare nuts, apply specified torque.
- When removing the flare nuts from the tubing connections, or when tightening them after connecting the tubing, be sure to use two spanners.
 When tightening the flare nuts, use a torque wrench.
 If the flare nuts are over-tightened, the flare may be damaged, which could result in refrigerant leakage and cause injury or asphyxiation to room occupants.
- For the flare nuts at tubing connections, be sure to use the flare nuts that were supplied with the unit, or else flare nuts for R410A, R32 (type 2). The refrigerant tubing that is used must be of the correct wall thickness as shown in the table at right.

Because the pressure is approximately 1.6 times higher than conventional refrigerant R22 pressure, the use of ordinary flare nuts (type 1) or thin-walled tubes may result in tube rupture, injury, or asphyxiation caused by refrigerant leakage.

Tube diameter	Tightening torque (approximate)	Tube thickness
ø6.35 (1/4")	14 − 18 N · m {140 − 180 kgf · cm}	0.8 mm
ø9.52 (3/8")	34 – 42 N · m {340 – 420 kgf · cm}	0.8 mm
ø12.7 (1/2")	49 – 55 N · m {490 – 550 kgf · cm}	0.8 mm
ø15.88 (5/8")	68 – 82 N · m {680 – 820 kgf · cm}	1.0 mm

- In order to prevent damage to the flare caused by over-tightening of the flare nuts, use the table on the right as a guide when tightening.
- When tightening the flare nut on the liquid tube, use an adjustable wrench with a nominal handle length of 200 mm.


5-3. Insulating the Refrigerant Tubing

Tubing Insulation

Must ensure that pipe-work shall be protected from physical damage.

- Thermal insulation must be applied to all units tubing, including distribution joint (field supply).
 - * For gas tubing, the insulation material must be heat resistant to 120°C or above. For other tubing, it must be heat resistant to 80°C or above.

Two tubes arranged together



Insulation material thickness must be 10 mm or greater.

If the conditions inside the ceiling exceed DB 30°C and RH 70%, increase the thickness of the gas tubing insulation material by 1 step.



CAUTION

If the exterior of the outdoor unit valves has been finished with a square duct covering, make sure you allow sufficient space to access the valves and to allow the panels to be attached and removed.

Additional Precautions For R32 Models



Ensure to do the re-flaring of pipes before connecting to units to avoid leaking.

To prevent the ingress of moisture into the joint which could have the potential to freeze and then cause leakage, the joint must be sealed with suitable silicone and insulation material. The joint should be sealed on both liquid and gas side.

Insulation material and silicone sealant. Please ensure there are no gaps where moisture can enter the joint.

Silicone Sealant must be neutral cure and ammonia free. Use of silicone containing ammonia can lead to stress corrosion on the joint and cause leakage.


Taping the flare nuts

Wind the insulating tape around the flare nuts at the gas / liquid tube connections.

Then cover up the tubing connections with the flare insulator.

Insulation material

The material used for insulation must have good insulation characteristics, be easy to use, be age resistant, and must not easily absorb moisture.



NOTE

If noise bothers you from the area between indoor and outdoor units' connection pipes, it is effective to wind the soundproofing materials (field supply) to reduce noise.




CAUTION

After a tube has been insulated, never try to bend it into a narrow curve because it can cause the tube to break or crack.

Never grasp the drain or refrigerant connecting outlets when moving the unit.

5-4. Taping the Tubes

- (1) At this time, the refrigerant tubes (and electrical wiring if local codes permit) should be taped together with armoring tape in 1 bundle. To prevent condensation from overflowing the drain pan, keep the drain hose separate from the refrigerant tubing.
- (2) Wrap the armoring tape from the bottom of the outdoor unit to the top of the tubing where it enters the wall. As you wrap the tubing, overlap half of each previous tape turn.
- (3) Clamp the tubing bundle to the wall, using 1 clamp approx. each meter.




NOTE

Do not wind the armoring tape too tightly since this will decrease the heat insulation effect. Also ensure that the condensation drain hose splits away from the bundle and drips clear of the unit and the tubing.



After finishing insulating and taping over the tubing, use sealing putty to seal off the hole in the wall to prevent rain and draft from entering.



6. HOW TO INSTALL THE TIMER REMOTE CONTROLLER OR HIGH-SPEC WIRED REMOTE CONTROLLER (OPTIONAL PART)

NOTE

Refer to the Installation Instructions attached to the optional Timer Remote Controller or optional High-spec Wired Remote Controller.

7. HOW TO INSTALL WIRELESS REMOTE CONTROLLER

NOTE

Refer to the Installation Instructions attached to the optional Wireless Remote Controller.


8. TEST RUN

8-1. Precautions


- Request that the customer be present when the test run is performed.
 At this time, explain the operation manual and have the customer perform the actual steps.
- Check that the 220 240 VAC power is not connected to the inter-unit control wiring connector terminal.
 - * If 220 240 VAC is accidentally applied, the indoor unit control PCB fuse will blow in order to protect the PCB. In this case, make the wiring correctly.

Then disconnect the 2P connectors (OC) that are connected to the indoor unit control PCB, and replace them with 2P connectors (EMG).

If operation is still not possible after changing the brown connectors, cut the jumper on the indoor unit control PCB. (Be sure to turn the power OFF before performing this work.)



8-2. Test Run Procedure



8-3. Items to Check Before the Test Run

- (1) Check that the indoor and outdoor units have correct combination.
- (2) Turn the remote power switch ON at least 5 hours in advance in order to energize.
- (3) Fully open the closed valves on the liquid tubing and gas tubing sides.
- (4) Separate the power supply in accordance with the types of system.
- (5) In the case of conditions below, restore the detailed settings code nos. 11, 12, 13, 14 of all indoor units in the system to the factory setting and then set up the auto address setting.
 - Indoor unit has been communicated with another outdoor unit before.
 - One or more PCBs of indoor units in the system are replaced.
 - Detailed setting "Code no." 11 is different from correct indoor unit capacity.
 - Detailed setting "Code no." 12, 13 or 14 doesn't match for system.
 - E15, E16 or L09 alarm occurs.
 - The "Assigning" screen appears on the LCD display for more than 10 minutes.

* Factory setting

XX : Code no.	XX : Code no. Item	
11	Indoor unit capacity	0000
12	System address	0099
13	Indoor unit address	0099
14	Group control address	0099

List of detailed setting items code nos. 11, 12, 13, 14

Code no.	Item	Set data						
Code no. Item		No.		Description	No.		Description	
		0005	36	S-3650PF3E (36) F3	0007	45	S-3650PF3E (45) F3	
11	Indoor unit	0009	56	S-3650PF3E (50) F3	0011	71	S-6071PF3E (60) F3	
11	capacity	0012	90	S-6071PF3E (71) F3	0015	112	S-1014PF3E (100) F3	
		0017	140	S-1014PF3E (125) F3	0018	160	S-1014PF3E (140) F3	
		0001	Unit	no. 1				
		0002	Unit	no. 2				
10	System	0003	Unit	Unit no. 3				
12	address	5	5					
		0030	Unit	Unit no. 30				
		0099 Not set						
		0001 Unit no. 1						
		0002	Unit	no. 2				
13	Indoor unit	0003	Unit	no. 3				
13	address	ζ ζ						
		0064	Unit	no. 64				
		0099	0099 Not set					
		0000	Indiv					
14	Group control	0001	Main unit (One of the group-control indoor units)					
14	address	0002	Sub unit (All group-control indoor units except for main unit)					
	0099 Not set							

^{*} Code no. is displayed with 6 digits in wired remote controller, CZ-RTC6 series. In this case, read as follows.

e.g., $11 \rightarrow 000011$

NOTE

The Item code numbers 11, 12, 13 and 14 can automatically be changed to the appropriate settings from factory settings listed in the previous page by making the auto address settings according to the connected outdoor unit capacity and the number of indoor units. If needed to reset the settings after once changed, return all the item codes to the factory shipment-time settings. It is necessary to set the auto address settings once again.


NOTE

In case of checking and changing before setting up the address settings in group connection, turn on only the power of the system to be checked and changed. If you turn on the power to all systems before address settings, the settings of all indoor units may not be seen correctly. After changing, turn off the power supply within 2 minutes or carry out the auto address setting procedures immediately. If the power of the system switched on for a while, the auto address setting may start as a single system and it might not match the multiple systems.

How to check and change code nos. 11,12,13,14

<Pre><Procedure of CZ-RTC5B> Stop the system before performing these steps.

(1) Keep pressing the , , and buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.



(2) Press the ▼ or ▲ button to see each menu. If you wish to see the next screen instantly, press the or ▶ button. Select "8. Detailed settings" on the LCD display and

Select "8. Detailed settings" on the LCD display and press the button.

The "Detailed settings" screen appears on the LCD display.


(3) Select the "Unit no." by pressing the ▼ or ▲ button for changes.


NOTE


If the address setting is not set up correctly, the "ALL" will be displayed in the "Unit no.".

(4) Select the "Code no." by pressing the or button. Change the "Code no." to "XX" by pressing the or button (or keeping it pressed).









(5) Select the "Set data" by pressing the or button. Select one of the Setting Data "YYYY" by pressing the or button.

Then press the __ button.

If you wish to change the selected indoor unit, follow Step (3).

(6) Press the button to finish.

The "Exit detailed settings and restart?" (Detailed settingend) screen appears on the LCD display.

Select "YES" and press the ____ button.


(Return to normal remote controller display.)



- (1) Press and hold the , and buttons simultaneously for 4 seconds or longer.
- (2) If group control is in effect, press the button to set. At this time, the fan at the indoor unit begins and select the address (unit no.) of the indoor unit operating.



If the address setting is not set up correctly, the "ALL" will be displayed in the "Unit no.".



- (3) Designate the item code "XX" by adjusting the Temperature Setting ▽/△ buttons.
- (5) Press the button.

 (The display stops blinking and remains lit, and setting is completed.)


 If you wish to change the selected indoor unit, follow Step (2).
- (6) Press the button to return to normal remote controller display.


<Pre><Pre>cedure of CZ-RTC6 series>

Stop the system before performing these steps.

(1) Keep pressing the , and buttons simultaneously for 4 or more seconds.

The "Maintenance func" screen appears on the LCD display.





(2) Press the or button to see each menu.

Select "Detailed settings" on the LCD display and press the button.

The "Detailed settings" screen appears on the LCD display.

(3) Select the "Unit no." by pressing the ✓ or ✓ button.

After selecting "Unit no.", press the ✓ button and proceed to Step (4).



If the address setting is not set up correctly, the "ALL" will be displayed in the "Unit no.".

If the button is pressed, proceed to Step (6).

(4) Keep pressing the button for 2 seconds or more during selecting "Code no.".

Change the "Code no." one digit at a time so that it becomes [0000XX] along with the following procedures.

Change the value by pressing the or button.

After changing the value, press the button and set the next digit.

Change the value by pressing the or button.

After changing the value, press the button and set the next digit.











Fig. A



Fig. B

Change the value by pressing the or button.

After changing all digits, press the button and proceed to Step (5).



Fig. C

- (5) Select one of the Setting Data "YYYY" by pressing the or button.
 - After selecting "Set data", press the button. (If setting continuously, follow the procedures from Fig. A.)

 If you wish to change the selected indoor unit or finish setting, press the button twice (the display returns to Step (3)).



Fig. D

(6) If the button is pressed under the display Step (3), the following display (Detailed setting-end screen) appears.

Then select "YES" by pressing the or button and press the button.






8-4. Check the Combination (wiring) of Indoor and Outdoor Units

Connection cable between outdoor and indoor unit has 2 types; One is 2-line connection and the other is 3-line connection. Check the type of the outdoor unit terminal board as illustrated below and make connection.

 If U1 and U2 are shown on the terminal board, it is for 2-line connection.


^{*} See the example in Section 4-3.



Inter-unit (between outdoor and indoor units) control wiring

If 1, 2 and 3 are shown on the terminal board, it is for 3-line connection.

* See the example in Section 4-3.



The examples above show the outdoor unit terminal boards. Carefully refer to the outdoor unit installation instructions.

8-5. Address Setting: 2-LINE CONNECTION

NOTE

The displays of the earth, outdoor unit power supply wiring and earth leakage circuit breaker are omitted.


8-5-1. Basic connection 1 : Single type and simultaneous multiple operations

- Simultaneous multiple operations: It is possible to operate maximum 4 (double-twin) indoor units within one outdoor unit. (Only specified indoor unit combination.
 Independent operation is not possible by connecting an individual remote controller.)
- It is not necessary to make setting of the refrigerant system address.
- When turning on all indoor and outdoor units, the auto address will start.
 It takes maximum 10 minutes. LED1 and LED2 of outdoor unit control PCB blink alternately during auto address setting.
 When finished, LEDs go off.
- When the auto address setting is completed, wait at least 1 minute and 30 seconds. Then start the operation.

Single type

System address rotary switch (Factory shipment: "0") Outdoor unit Inter-unit control wiring Remote control wiring Remote controller


Simultaneous multiple (double-twin) operations



8-5-2. Basic connection 2 : Group control operation (when not using integrated control system)

- Before turning on the power (earth leakage circuit breaker), make refrigerant system auto address setting. (See Section 8-5-5.)
- Turn on the system 1 indoor and outdoor units (earth leakage circuit breaker) and make indoor unit auto address setting. (See Section 8-7.)


Two group control



 While keeping the system 1 power on, turn on the system 2 indoor and outdoor units (earth leakage circuit breaker).

Then make auto address setting of the indoor unit. (See Section 8-7.)

Two group control




outdoor unit. Then make auto address setting.

* When making group control more than two systems, set up each system address rotary switch of the outdoor unit and specify the outdoor unit by using the remote controller or short circuit the auto address pin of the

8-5-3. Basic connection 3: Example of link wiring (when using integrated control system)


- Before turning on the power (earth leakage circuit breaker), set the system address of each outdoor unit with the rotary switch.
- Turn on the power supply (earth leakage circuit breaker) of each system, make each system auto address setting by using the remote controller or short-circuiting the auto address pin of outdoor unit. (See Sections 8-7, 8-8).



^{*} It is possible to connect maximum 8 indoor units with one remote controller.

8-5-4. Basic connection 4: Group control with 3-LINE CONNECTION unit

* Remote control wiring is necessary in all indoor units.
 Make auto address setting following the procedure "8-5-2. Basic connection 2".



^{*} If two (2) remote controllers are used, one (1) remote controller is set to "main" and the other is set to "sub". (See Section 8-11.)


^{*} In the case of 3-line connection system, auto address setting cannot be made by short-circuiting the outdoor auto address pin.

8-5-5. Setting the Outdoor unit system addresses

For basic wiring diagram (Set the system address: 1)

Outdoor unit control PCB

System address rotary switch (Set to "0" at time of shipment)



System address No.	System address 10 digit (2P DIP switch)	System address 1 place (Rotary switch)
0 Auto address (Setting at shipment = "0")	Both OFF ON Û 1 2 OFF	"0" setting
1 (If outdoor unit is No. 1)	Both OFF ON ON 1 OFF	"1" setting

8-6. Address Setting: 3-LINE CONNECTION

NOTE

The displays of the earth, outdoor unit power supply wiring and earth leakage circuit breaker are omitted.


8-6-1. Basic connection 1 : Single type and simultaneous multiple operations

- Simultaneous multiple operations: It is possible to operate maximum 4 (double-twin) indoor units within one outdoor unit. (Only specified indoor unit combination.
 Independent operation is not possible by connecting an individual remote controller.)
- It is not necessary to make setting of the refrigerant system address.
- When turning on all indoor and outdoor units, the auto address will start.
 It takes maximum 10 minutes.
- When the auto address setting is completed, wait at least 1 minute and 30 seconds. Then start the operation.

Single type

Outdoor unit Connection cable between outdoor and indoor unit Indoor unit Remote control wiring Remote controller


Simultaneous multiple (double-twin) operations



8-6-2. Basic connection 2 : Group control operation (when not using integrated control system)

 Turn on the system 1 indoor and outdoor units (earth leakage circuit breaker) and make indoor unit auto address setting. (See Section 8-7.)


Two group control



 While keeping the system 1 power on, turn on the system 2 indoor and outdoor units (earth leakage circuit breaker).


Then make auto address setting of the indoor unit. (See Section 8-7.)

Two group control



8-6-3. Basic connection 3: Example of link wiring (when using integrated control system)


 Turn on the power of each system, specify a different system address for each system and make auto address setting from each remote controller. (See Section 8-7.)



^{*} It is possible to connect maximum 8 indoor units with one remote controller.

8-6-4. Basic connection 4: Group control with different refrigerant unit

* Remote control inter-unit control wiring is necessary in all indoor units.
 Make auto address setting following the procedure "8-6-2. Basic connection 2".



^{*} If two (2) remote controllers are used, one (1) remote controller is set to "main" and the other is set to "sub". (See Section 8-11.)

^{*} In the case of 2-line connection system, auto address setting from the outdoor unit can be also made by specifying address with the rotary switch and short-circuiting the auto address pin. (See Section 8-8.)

8-7. Auto Address Setting Using the Remote Controller

Auto Address Setting from the High-spec Wired Remote Controller (CZ-RTC5B)

(1) Keep pressing the , and buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.




(2) Press the ▼ or ▲ button to see each menu.


If you wish to see the next screen instantly, press the
 or ▶ button.

Select "9. Auto address" on the LCD display and press the Jutton.

(3) The "Auto address" screen appears on the LCD display.







(4) Select the "O/D unit no." by pressing the or button.

Select one of the "O/D unit no." by pressing the or button and press the button for auto address setting.

Approximately 10 minutes are required.

When auto address setting is completed, the units return to normal stopped status.

Auto Address Setting* from the Remote Controller (CZ-RTC4)


NOTE

- Selecting each refrigerant system individually for auto address setting
- Auto address setting for each system : Item code "A1"
- (1) Press the remote controller timer time button and button at the same time.(Press and hold for 4 seconds or longer.)
- (2) Next, press either the temperature setting ▽/△ button. (Check that the item code is "A1".)
- (3) Use either the button to set the system No. to perform auto address setting.
- (4) Then press the set button.


(Auto address setting for one refrigerant system begins.) (When auto address setting for one system is completed, the system returns to normal stopped status.)

<Approximately 10 minutes are required.>

(During auto address setting, " **SETTING** " is displayed on the remote controller.



(5) Repeat the same steps to perform auto address setting for each successive system.




Auto Address Setting from the Wired Remote Controller (CZ-RTC6 series)

(1) Keep pressing the ≡, △ and ⊸ buttons simultaneously for 4 or more seconds.

The "Maintenance func" screen appears on the LCD display.





(2) Press the ✓ or ✓ button to see each menu.

Select "Auto address" on the LCD display and press the button.




(3) The "Auto address" screen appears on the LCD display. Select the "Code no." to "A1" by pressing the ✓ or ✓ button.



After selecting "Code no.", press the button and proceed to Step (4). If the button is pressed, proceed to Step (5).

(4) Select one of the "O/D unit no." for auto address by pressing the ✓ or ✓ button.



After selecting "O/D unit no.", press the — button.





transition







Approximately 10 minutes are required.

When auto address setting is completed, the units return to normal stopped status.

(5) If the button is pressed under the display Step (3), the following display (Auto address-end screen) appears.

Then select "YES" by pressing the or button and press the button.



8-8. How to Set Refrigerant System Address (Only outdoor PZ2 and PZH2 series)

- Turn on the power in the indoor and outdoor units of the refrigerant system 1.
- Switch the power on and wait at least 1 minute and 30 seconds or more. Short-circuit the
 auto address pin of the outdoor unit with turned on and release. (LED1 and LED2 of the
 outdoor unit control PCB blink alternately and the address setting of the indoor unit is started.
 When completed, LEDs go off.)
 - <It takes about 10 minutes until it finished.>
 - Auto address pin: If you once again short-circuit the auto address pin before completion when the auto address started, the auto address will stop.
- Turn on the different refrigerant system's indoor and outdoor units and wait at least 1 minute and 30 seconds or more. Then short-circuit the auto address pin of the outdoor unit and release.
- Repeat the same procedure and complete the auto address setting of each system.
- When the address setting is completed, wait at least 1 minute and 30 seconds or more. Then start the operation.

8-9. Checking the Indoor Unit Addresses

Use the remote controller to check the indoor unit address.

CZ-RTC5B (High-spec wired remote controller)

(1) Keep pressing the , and buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.



(2) Press the ▼ or ▲ button to see each menu.

If you wish to see the next screen instantly, press the
 or ▶ button.

Select "7. Simple settings" on the LCD display and press the — button.


(3) The "Simple settings" screen appears on the LCD display.


Select the "Unit no." by pressing the ▼ or ▲ button for changes.


* The initial display is "ALL".

The indoor unit fan operates only at the selected indoor unit.

(4) Press the button and select "YES" to restart.








CZ-RTC4 (Timer remote controller)

<If 1 indoor unit is connected to 1 remote controller>

- (1) Press and hold the putton and button for 4 seconds or longer (simple settings mode).
- (2) The address is displayed for the indoor unit that is connected to the remote controller.(Only the address of the indoor unit that is connected to the remote controller can be checked.)
- (3) Press the putton again to return to normal remote controller mode.


Number changes to indicate which indoor unit is currently selected.



<If multiple indoor units are connected to 1 remote controller (group control)>

- (1) Press and hold the → button and ⊕/⊕ button for 4 seconds or longer (simple settings mode).
- (2) "ALL" is displayed on the remote controller.
- (3) Next, press the UNIT button.
- (4) The address is displayed for 1 of the indoor units which is connected to the remote controller. Check that the fan of that indoor unit starts and that air is discharged.
- (5) Press the button again and check the address of each indoor unit in sequence.
- (6) Press the putton again to return to normal remote controller mode.

Number changes to indicate which indoor unit is currently selected.




CZ-RTC6 series (Wired Remote Controller)

(1) Keep pressing the ≡, △ and ➡ buttons simultaneously for 4 or more seconds.

The "Maintenance func" screen appears on the LCD display.





- (2) Press the or button to see each menu.

 Select "Simple settings" on the LCD display and press the button.
- (3) The "Simple settings" screen appears on the LCD display. Select the "Unit no." by pressing the ✓ or ✓ button for changes.
 - * The initial display is "ALL".

The indoor unit fan operates only at the selected indoor unit.

(4) Press the button and select "YES" to restart.





8-10. Test Run Using the Remote Controller

CZ-RTC5B (High-spec wired remote controller)

This mode places a heavy load on the machines. Therefore use it only when performing the test run.

(1) Keep pressing the , and buttons simultaneously for 4 or more seconds. The "Maintenance func" screen appears on the LCD display.



(2) Press the ▼ or ▲ button to see each menu. If you wish to see the next screen instantly, press the or ▶ button.


Select "4. Test run" on the LCD display and press the button.


Change the display from "OFF" to "ON" by pressing the ▼ or ▲ button. Then press the ⊸ button.


- (3) Press the button. "TEST" will be displayed on the LCD display.
- (4) Press the button. Test run will be started. Test run setting mode screen appears on the LCD display.
 - The test run can be performed using the HEAT, COOL, or FAN operation mode.
 - The temperature cannot be adjusted when in test run mode.
 - If correct operation is not possible, a code is displayed on the remote controller LCD display. (Regarding the alarm contents, see the SUPPLEMENT at the end of this manual.)
- (5) After the test run is completed, proceed from Step (1) and change to "OFF" at Step (2).
 - To prevent continuous test run, this remote controller includes a timer function that cancels the test run after 60 minutes.


NOTE


- The outdoor units will not operate for approximately 3 minutes after the power is turned ON and after operation is stopped.
- If the test run is performed using the wired remote controller, operation is possible even if the cassette-type ceiling panel has not been installed. ("P09" display does not occur.)











CZ-RTC4 (Timer remote controller)

This mode places a heavy load on the machines. Therefore use it only when performing the test run.

(1) Press the remote controller putton for 4 seconds or longer.


Then press the button.

"TEST" appears on the LCD display while the test run is in progress.

- The test run can be performed using the HEAT, COOL, or FAN operation mode.
- The temperature cannot be adjusted when in test run mode.
- If correct operation is not possible, a code is displayed on the remote controller LCD display. (Regarding the alarm contents, see the SUPPLEMENT at the end of this manual.)
- (2) After the test run is completed, press the putton again. Check that "TEST" disappears from the LCD display.
 - To prevent continuous test run, this remote controller includes a timer function that cancels the test run after 60 minutes.

NOTE

- The outdoor units will not operate for approximately 3 minutes after the power is turned ON and after operation is stopped.
- If the test run is performed using the wired remote controller, operation is possible even if the cassette-type ceiling panel has not been installed. ("P09" display does not occur.)




CZ-RTC6 series (Wired Remote Controller)

This mode places a heavy load on the machines. Therefore use it only when performing the test run.

(1) Keep pressing the ≡, △ and ➡ buttons simultaneously for 4 or more seconds.

The "Maintenance func" screen appears on the LCD display.





(2) Press the ✓ or △ button to see each menu.

Select "Test run" on the LCD display and press the ✓ button.

Change the display from "OFF" to "ON" by pressing the or button.

Then press the — button.

- (3) Press the button. "TEST" will be displayed on the LCD display.
- (4) Press the button. Test run will be started.

 Test run setting mode screen appears on the LCD display.
 - The test run can be performed using the HEAT, COOL, or FAN operation mode.
 - The temperature cannot be adjusted when in test run mode.
 - If correct operation is not possible, a code is displayed on the remote controller LCD display. (Regarding the alarm contents, see the SUPPLEMENT at the end of this manual.)
- (5) After the test run is completed, proceed from Step (1) and change to "OFF" at Step (2).
 - To prevent continuous test run, this remote controller includes a timer function that cancels the test run after 60 minutes.

NOTE

- The outdoor units will not operate for approximately 3 minutes after the power is turned ON and after operation is stopped.
- If the test run is performed using the wired remote controller, operation is possible even if the cassette-type ceiling panel has not been installed. ("P09" display does not occur.)










8-11. Main-Sub Remote Controller Control

One (1) indoor unit can be controlled by two (2) wired remote controllers. In the case of using 2 remote controllers, one of them needs to be designated as the sub remote controller.

Connecting 2 remote controllers to control 1 indoor unit



Remote controller setting mode (CZ-RTC5B)


(1) Press and hold the , and for 4 seconds or more simultaneously.





(3) Select the "Code no." and "Set data".







Codo no	lka na	Set	data
Code no.	Item	0000	0001
01	Main/Sub	Sub	Main


- (4) Press <u></u>_____.
 - After selecting "YES", the unit restarts.

Remote controller setting mode (CZ-RTC4)

- (1) Press and hold the and buttons for several seconds simultaneously.
- (2) Select the Code no. ▽/△
- (3) Select the Set data. ▼DAY/TIME/TIMER →→ □

The indicator illuminates after blinking. Press .

Code no.	ltom	Set	data
Code no.	Item	0000	0001
01	Main/Sub	Sub	Main



Remote controller setting mode (CZ-RTC6 series)


(1) Press and hold the ≡, △ and ← for 4 seconds or more simultaneously.

(2) Select "RC. setting mode".




(3) Select the "Code no." and "Set data".









Code no.	Item	Set data		
Code no.	item	0000	0001	
01	Main/Sub	Sub	Main	

- (4) Press
 - After selecting "YES", the unit restarts.

9. CHECKLIST AFTER INSTALLATION WORK

Work List	No.	Content	Check ☑	Possibility of Failure & Checkpoint
Installation	1	Are the indoor units installed following the content of Section "2. SELECTING THE INSTALLATION SITE"?		There is a possibility of light injure or loss of property.
	2	In the case of multiple installation: Is there a wrong tubing connection with another system?		The unit is inoperated or the refrigerant flows into the inoperative unit and the leakage is
	3	In the case of multiple installation: Is there a wrong wiring connection with another system?		expected. Check if there is a wrong tubing or wiring connection with another system.
	4	Is the earth leakage circuit breaker (all-pole switching function provided) installed?		
Tubin a 0	5	Is there any wrong installation of optional parts or wrong wiring?		
Tubing & Wiring	6	Was the ground wire work performed?		Power failure or short circuit may cause electric
	7	Are there any wrong power supply wiring, wrong connection wire, wrong signal wire or loose screw?		shock or fire. Check installation work and ground wire work.
	8	Is the thickness of wire in accordance with rule?		
	9	Is the power-supply voltage equal to the nameplate of the unit?		
	10	Was the check of the airtight test, flared tube fitting and gas leakage on the welded portion performed?		If the gas leakage occurs, the unit quality not only becomes inferior but affects environment. Repair it as quickly as possible.
	11	Has the adhesive been applied to the drain connecting portion (resin portion) of the indoor unit?		The resin portion cracks after a few months and it may cause water drain.
Drain Check	12	Is there water leakage?		
	13	Indoor unit drain pipe has a downward gradient (1/100 or more) by rule. Is the drain water flowing smoothly?		Since there is a possibility of water drain, repair the drain pipe if the drain failure or water drain occurs.
Heat Insulation	14	Was the heat insulation work at a suitable location including the flared tube fitting (refrigerant tube & drain pipe) performed properly?		The quality of unit not only becomes inferior but there is a possibility of the water drain. So, perform the heat insulation work properly.
	15	Did the abnormal sound occur?		Check if there is a fan contact or distortion of the indoor unit.
Test Run	16	Did the cool and warm airflow discharge from the indoor unit?		Check if the unit does not operate or there is a wrong tubing or wiring connection with another system.

10. EXTERNAL STATIC PRESSURE SETTING

For middle static pressure duct type indoor units, the ventilating resistance so-called "external static pressure" becomes greatly different depending on the connected duct length, shape, number of air outlet ports and types of filters.


When installing this unit, be sure to carry out the external static pressure setting in order to operate in the rated airflow volume.

Choose one of the following methods from "a", "b", "c" or "d" as shown in the flow chart (within the dotted lines) and then make the setting accordingly.

- a. No setting modification:
 - Use-as-is at shipment (there are cases in which the setting may differ from the shipment setting when reset after once setting the external static pressure.)
- b. Manual setting (set with the indoor unit control PCB):
 For high static pressure. Switching method with the short-circuit connector.
- c. Manual setting (set with the wired remote controller): Low static pressure ~ high static pressure
- d. Auto airflow volume setting (set on the wired remote controller):

 Air outlet volume is automatically adjusted to the rated airflow volume with the auto airflow volume control operation.

Flow of External Static Pressure



NOTE

- (1) Check the following items before performing the setting-check operations or auto airflow volume operations.
 - 1) Check to make sure that the electrical wiring and ducting have been completed. Activate the stand-by mode. In particular, make sure that the closed damper located in the middle of the duct is open, if installed. Also, make sure that air filters have been installed inside the air inlet duct.

Check to make sure air is not leaking from the joints.

- 2) If multiple air outlets and air inlets are included, adjust the airflow volume ratio of all of them until they meet the design airflow ratio.
- 3) Make sure the address setting has been completed.
- (2) The operation check will be completed in approximately three minutes if the settings have been made correctly. The settings will be modified if they are out of the range of use (maximum 30 minutes). If this is not completed within 31 minutes, check whether the air speed is set to "H" or not.
- (3) See Tables 10-2, 10-3 or 10-4 and Fig. 10-2 for details on the relationship between the value of item code "b0" and the external static pressure.
- (4) When set in group control (connecting multiple indoor units with one wired remote controller), set each indoor unit to item code "b0".
 When amending the setting after selecting [b. Manual setting] (due to airflow path changes, etc.), it is necessary to cancel [b. Manual setting] (change the dip switch). When [b. Manual setting] has not been cancelled, [c. Manual setting] and [d. Auto airflow volume setting] will be activated if selected, but [b. Manual setting] takes precedence when the power is switched back on after power outages, etc.
- (5) If this is not completed within 8 minutes, check the operation mode, air speed and air inlet temperature.
- (6) When set in group control (connecting multiple indoor units with one wired remote controller), the test run operations display will disappear once the external static pressure setting check or auto airflow volume control operation check have been completed for the main unit. However, it is not possible to determine whether sub-units have completed. The test run operation display will disappear after one hour even if the external static pressure setting check or auto airflow volume control operation check have not been completed.



CAUTION

- Be sure to check that the external static pressure is within the range for use and then make the setting. Failure to observe this may result in insufficient airflow or water leakages. See Fig. 10-2 for the external static pressure setting range.
- There are cases in which automatic variable dampers and other mounted items may trigger the P12 alarm on systems that modify the external static pressure when the auto airflow volume control operations or setting check operations are carried out if high external static pressure is lowered. In this event, lower the dampers, etc., so that the external static pressure reaches its lowest level, and then carry out the auto airflow volume control operations or setting check operations.
- Be sure to set the [External Static Pressure Setting] once again after amending the airflow path for the duct or air outlet after setting the external static pressure.
- Set the air inlet temperature within the range for use. The auto airflow volume control will not function if the air inlet temperature is over 45°C or if operation is other than fan mode.

10-1. How to Set on Indoor Unit Control PCB

- 1. Turn off the power breaker to halt the supply of electricity to the indoor unit control PCB.
- 2. Open the electrical component box cover, then check the indoor unit control PCB. (Fig. 10-1)
- 3. Change the dip switch (SW001) of the indoor unit control PCB according to the setting selected in Table 10-1.

Table 10-1

External static pressure of the rated airflow volume	DIP switch
10 Pa	ON
50 Pa	ON 1 2 3
110 Pa	ON 1 2 3





Fig. 10-1

10-2. Operating the High-spec Wired Remote Controller (CZ-RTC5B)



How to set the external static pressure


Keep pressing the , and buttons simultaneously for 4 or more seconds.

The "Maintenance func" screen appears on the LCD display.




2. Press the ▼ or ▲ button to see each menu.

If you wish to see the next screen instantly, press the or button. Select "8. Detailed settings" on the LCD display and press the button.




The "Detailed settings" screen appears on the LCD display.

3. Select the "Unit no." by pressing the ▼ or ▲ button for changes.



4. Select the "Code no." by pressing the or button.
Change the "Code no." to "B0" by pressing the or button (or keeping it pressed).



5. Select the "Set data" by pressing the button.

Select one of the "Set data" among "0001" – "0010" according to the desired external static pressure setting by pressing the

▼ or ▲ button.

Then press the → button.

(See Table 10-2.)

When setting to auto airflow volume control:

Select the setting data to "-002". Then press the button.

Table 10-2 Setting the external static pressure

	Item code					
3650	6071		1014			
	Out	door unit	type			
_	-	100	125	140	В0	
1	l static pr olume (P		the rated			
15	50	150	15	50	0010	
14	10	140	14	40	0009	
13	30	130	130		8000	
12	20	120	120		0007	
11	110		110		0006	
9	0	90	9	0	0005	
7	0	70	7	0	0004	
5	50 50 50 *				0003	
3	30 *		3	0	0002	
1	10 10 10					
No auto	No auto airflow volume setting					
Auto air	flow volui	me settin	g		-002	

^{*} Airflow volume setting at shipment

NOTE:


Failure to set this parameter may result in decreased airflow and condensation.

6. Select the "Unit no." by pressing the

or ▶ button and press the button.

The "Exit detailed settings and restart?" (Detailed setting-end) screen appears on the LCD display.


Select "YES" and press the button. When the setting is completed, perform the test run for the external static pressure setting described in "Auto External Static Pressure Setting Operation".



Auto External Static Pressure Setting Operation

7. Keep pressing the , and buttons simultaneously for 4 or more seconds.


The "Maintenance func" screen appears on the LCD display.




8. Press the or button to see each menu.

If you wish to see the next screen instantly, press the ■ or ▶ button.

Select "4. Test run" on the LCD display and press the button.




The "Test run" screen appears on the LCD display.




Change the display from "OFF" to "ON" by pressing the ▼ or ▲ button.


Then press the ↓ button.



The "Maintenance func" screen appears on the LCD display.




9. Press the button. "TEST" will be displayed on the LCD display.




10. Press the _____ button. Test run will be started.


Test run setting mode screen appears on the LCD display.




11. Set the operation mode to " **\$\$** (MODE FAN)" and fan speed mode to

" 🃶 (FAN SPEED)" by pressing the






The fan motor will be activated, the auto external static pressure setting operation and setting-check operation will be performed for about 3 to 30 minutes. The fan speed will change automatically while these operations are in progress. When these operations completed, "TEST" will be disappeared from the LCD display.



NOTE:

The auto external static pressure setting operation and setting-check operation will not be performed unless " \$\$ (MODE FAN)" and " (FAN SPEED)" have been selected.


12. Press the button.
The LCD display will be returned to the initial screen.



NOTE:

Failure to set this parameter may result in decreased airflow and condensation.

10-3. Operating the Timer Remote Controller (CZ-RTC4)



10-3-1. Setting Item Code " []"

- Press and hold down the , and buttons simultaneously for 4 or more seconds.
 - (SETTING, the unit no., item code and detailed data will blink on the LCD display.)
- 3. Specify the "♠↓" item code by pressing the ▽/△ buttons for the temperature setting buttons and confirm the values.

 ("- ☐ ☐ ☐ f" set at shipment)
- 4. Press the \(\sum_{\pi}\)/\sum_ buttons for the time to amend the values for the set data. See Table 10-3 and Fig. 10-2 and select a value between "\(\mathbb{II}\)\ \(\mathbb{I}\)\ \(\math
- 5. Press the button.
 The display will stop blinking and remain illuminated.
- 6. Press the putton. The fan motor will stop operating and the LCD display will return to the normal stop mode.

Table 10-3 Setting the external static pressure


<u> </u>					
	Item code				
3650 607	1	1014			
	Outdoor unit	type			
_	100	125	140	60	
External station		the rated			
150	150	15	50	00 10	
140	140	14	10	00 09	
130	130	10	30	00 08	
120	120	120		00 07	
110 110 1		10	00 06		
90 90 90			00 05		
70	70 70 70		00 04		
50	50	50 *		00 03	
30 *	40 *	30		00 02	
10 10 10				0001	
No auto airflo	w volume se	tting		-001	
Auto airflow v	olume settin	g		-002	

^{*} Airflow volume setting at shipment

NOTE:

Failure to set this parameter may result in decreased airflow and condensation.

10-3-2. Auto Airflow Volume Control Operations and External Static Pressure Setting-Check Operation



- Press and hold down the button for 4 or more seconds. "TEST" will be displayed on the LCD display.
- 2. Press the button to start the test run.
- 3. Select the operation mode \$\mathbb{K}\$ (Fan) by pressing the "" (Mode select) button.

 Then select the fan speed \$\mathbb{K}\$) by pressing the " (Fan speed) button.

NOTE

Auto airflow volume control operations and external static pressure setting-check operations will not be performed unless the above settings are made.

4. The fan motor will be activated and auto airflow volume control operations or external static pressure setting-check operations will be started.

The power of the airflow will change while these operations are in progress.

The external static pressure setting-check operations and auto airflow volume control operations will be completed in about 3 to 30 minutes.

"TEST" display will be disappeared from the LCD display.

5. Press the button to halt the test run.

10-4. Operating the Wired Remote Controller (CZ-RTC6 series)

Stop the system before performing these steps.

How to set the external static pressure

1. Keep pressing the ≡, △ and ➡ buttons simultaneously for 4 or more seconds.

The "Maintenance func" screen appears on the LCD display.



Press the ✓ or ✓ button to see each menu.
 Select "Detailed settings" on the LCD display and press the button.

The "Detailed settings" screen appears on the LCD display.

- Select the "Unit no." by pressing the or button.
 After selecting "Unit no.", press the button and proceed to Step 4.
 - If the button is pressed, proceed to Step 6.
- 4. Keep pressing the button for 2 seconds or more during selecting "Code no.".

Change the "Code no." one digit at a time so that it becomes [0000B0] along with the following procedures.

Change the value by pressing the or button.

After changing the value, press the button and set the next digit.

Change the value by pressing the or button.

After changing the value, press the button and set the next digit.

Change the value by pressing the ✓ or △ button.

After changing all digits, press the ✓ button and proceed to Step 5.














Fig. A



Fig. B



Fig. C

5. Select one of the "Set data" among "0001"—"0010" according to the desired external static pressure setting by pressing the
or

→ button.

(See Table 10-4.)

Fig. D

When setting to auto airflow volume control:

Select the setting data to "-002".

After selecting "Set data", press the button. (If setting continuously, follow the procedures from Fig. A.)

If you wish to change the selected indoor unit or finish setting, press the button twice (the display returns to Step 3).

Table 10-4 Setting the external static pressure

	Item code				
3650	6071		1014		
	Out	door unit	type		
-	_	100	125	140	В0
	l static pr olume (P		the rated		
15	50	150	15	50	0010
14	40	140	14	10	0009
13	30	130	130		8000
12	20	120	120		0007
1	10	110	110		0006
9	0	90 90			0005
7	70 70 70			0004	
5	50 50 50 *				0003
3	30 * 40 * 30		0002		
10 10 10					0001
No auto	airflow v	olume se	tting		-001
Auto ai	rflow volu	me settin	g		-002

^{*} Airflow volume setting at shipment

NOTE:

Failure to set this parameter may result in decreased airflow and condensation.

6. If the button is pressed under the display Step 3, the following display (Detailed setting-end screen) appears.

Then select "VES" by pressing the Step and putter and putters and putters.

Then select "YES" by pressing the ✓ or △ button and press the ✓ button.

Auto External Static Pressure Setting Operation

7. Keep pressing the

,

and


buttons simultaneously for 4 or more seconds.

The "Maintenance func" screen appears on the LCD display.

8. Press the ✓ or ✓ button to see each menu.

Select "Test run" on the LCD display and press the ✓ button.







The "Test run" screen appears on the LCD display.



Change the display from "OFF" to "ON" by pressing the

✓ or ↑ button.

Then press the **button**.



The "Maintenance func" screen appears on the LCD display.



9. Press the ≡ button. "TEST" will be displayed on the LCD display.



10. Press the button. Test run will be started. Test run setting mode screen appears on the LCD display. Current fan speed can be checked by pressing the button.



11. Set the operation mode to " \$\footnote{1}\text{ (MODE FAN)}" and fan speed buttons.



Then press the **button**.

The fan motor will be activated, the auto external static pressure setting operation and setting-check operation will be performed for about 3 to 30 minutes.

The fan speed will change automatically while these operations are in progress.


When these operations completed, "TEST" will be disappeared from the LCD display.



NOTE:


Failure to set this parameter may result in decreased airflow and condensation.


Indoor Units Type 3650 (36, 45)




Indoor Fan Performance

PQ diagram (Fig. 10-2)







External static pressure 140Pa, 70Pa




External static pressure 130Pa, 50Pa




External static pressure 120Pa, 30Pa



External static pressure 110Pa, 10Pa




Indoor Units Type 3650 (50)




Indoor Fan Performance

PQ diagram (Fig. 10-2)


External static pressure 150Pa, 90Pa




External static pressure 140Pa, 70Pa




External static pressure 130Pa, 50Pa




External static pressure 120Pa, 30Pa



External static pressure 110Pa, 10Pa




Indoor Units Type 6071 (60, 71)




Indoor Fan Performance

PQ diagram (Fig. 10-2)


External static pressure 150Pa, 90Pa




External static pressure 140Pa, 70Pa




External static pressure 130Pa, 50Pa



External static pressure 120Pa, 30Pa



External static pressure 110Pa, 10Pa




Indoor Units Type 1014 (100)




Indoor Fan Performance

PQ diagram (Fig. 10-2)


External static pressure 150Pa, 90Pa




External static pressure 140Pa, 70Pa




External static pressure 130Pa, 40Pa



External static pressure 120Pa, 30Pa



External static pressure 110Pa, 10Pa




Indoor Units Type 1014 (125)




Indoor Fan Performance

PQ diagram (Fig. 10-2)


External static pressure 150Pa, 90Pa




External static pressure 140Pa, 70Pa




External static pressure 130Pa, 50Pa



External static pressure 120Pa, 30Pa



External static pressure 110Pa, 10Pa




Indoor Units Type 1014 (140)




Indoor Fan Performance

PQ diagram (Fig. 10-2)


External static pressure 150Pa, 90Pa




External static pressure 140Pa, 70Pa




External static pressure 130Pa, 50Pa



External static pressure 120Pa, 30Pa



External static pressure 110Pa, 10Pa



11. APPENDIX

■ Care and Cleaning



- For safety, be sure to turn the air conditioner off and also to disconnect the power before cleaning.
- Do not pour water on the indoor unit to clean it. This will damage the internal components (fan motor, etc.) and cause an electric shock hazard.

Air intake and outlet side (Indoor unit)

Clean the air intake and outlet side of the indoor unit with a vacuum cleaner brush, or wipe them with a clean, soft cloth.

If these parts are stained, use a clean cloth moistened with water. When cleaning the air outlet side, be careful not to force the vanes out of place.



- Never use solvents or harsh chemicals when cleaning the indoor unit. Do not wipe plastic parts using very hot water.
- Some metal edges and the fins are sharp and may cause injury if handled improperly; be especially careful when you clean these parts.
- The internal coil and other components of outdoor unit must be cleaned regularly.
 Consult your dealer or service center.

Air filter

The air filter collects dust and other particles from the air and should be cleaned at regular intervals. If the air conditioner does not cool or warm, the air filter might be clogged. If the filter gets blocked, the efficiency of the air conditioner drops greatly. When cleaning the air filter, consult your dealer or service center.

NOTE

The frequency with which the filter should be cleaned depends on the environment in which the unit is used.

Clean the filter frequently for best performance in the area of dusty or oil spots regardless of filter status.

When maintaining the filter, it may necessary to use a stubby screwdriver.

<How to clean the filter>

Use a vacuum cleaner to remove light dust. If there is sticky dust on the filter, wash the filter in lukewarm, soapy water, rinse it in clean water, and dry it.

<How to remove the filter>

Remove the filter in reverse order under Section "3-2-2. Install the Filter".

In case of Installing the Duct (field supply)

Туре	F3
Period	(Depends on filter's specifications)

When cleaning the air filter, consult your dealer or service center.

/ CAUTION

- Certain metal edges and the condenser fins are sharp and may cause injury if handled improperly; special care should be taken when you clean these parts.
- Periodically check the outdoor unit to see if the air outlet or air intake is clogged with dirt or soot.
- The internal coil and other components must also be cleaned periodically. Consult your dealer or service center.

Care: After a prolonged idle period

Check the indoor and outdoor unit air intakes and outlets for blockage; if there is a blockage, remove it.

Care: Before a prolonged idle period

- Operate the fan for half a day to dry out the inside.
- Disconnect the power supply and also turn off the circuit breaker.
- Clean the air filter and replace it in its original position.
- Outdoor unit internal components must be checked and cleaned periodically. Contact your local dealer for this service.

■ Troubleshooting

If your air conditioner does not work properly, first check the following points before requesting service. If it still does not work properly, contact your dealer or a service center.

• Indoor unit

	Symptom	Cause	
Noise	Sound like streaming water during operation or after operation	 Sound of refrigerant liquid flowing inside unit Sound of drainage water through drain pipe 	
	Cracking noise during operation or when operation stops.	Cracking sound due to temperature changes of parts	
Odor Discharged air is smelled during operation.		Indoor odor components, cigarette odor and cosmetic odor accumulated in the air conditioner and its air is discharged. Unit inside is dusty. Consult your dealer.	
Dewdrop	Dewdrop gets accumulated near air discharge during operation	Indoor moisture is cooled by cool wind and accumulated by dewdrop.	
Fog Fog occurs during operation in cooling mode. (Places where large amounts of oil mist exist at restaurants.)		 Cleaning is necessary because unit inside (heat exchanger) is dirty. Consult your dealer as technical engineering is required. During defrost operation 	
Fan is rotating for a while even though operation stops.		 Fan rotating makes operation smoothly. Fan may sometimes rotate because of drying heat exchanger due to settings. Fan may sometimes rotate in internal cleaning operation mode for a while. 	
Dust		Dust accumulation inside indoor unit is discharged.	
Poor cooling or heating performance		The indoor unit is initially designed to control the indoor temperature detected by the built-in room sensor inside the indoor unit. Due to indoor unit installation position, however, the built-in sensor may occasionally sense temperature improperly; for example, temperature difference between the ceiling and floor, lighting apparatus, electric fan, windows or waist-high partition walls, etc. In this case, the unit does not operate properly at the desired temperature. You may change the use of the temperature sensor inside the indoor unit to that of the remote controller. Then the desired room temperature can be controlled properly. For details, consult your dealer.	

Check Before Requiring Services

Symptom	Cause	Remedy
Air conditioner does not run at all although power is turned	Power failure or after power failure	Press ON/OFF operation button on remote controller again.
on.	Operation button is turned off.	 Switch on power if breaker is turned off. If breaker has been tripped, consult your dealer without turning it on.
	Fuse blow out.	If blown out, consult your dealer.
Poor cooling or heating performance	Air intake or air discharge port of indoor and outdoor units is clogged with dust or obstacles.	Remove dust or obstruction.
	Fan speed switch is set to "Low".*	Change to "Medium" or "High".*
	Improper temperature settings	See Section "■ Tips for Energy Saving".
	Room is exposed to direct sunlight in cooling mode.	
	Doors and /or windows are open.	
	Air filter is clogged.	See Section "■ Care and Cleaning".
	Too much heat sources in room in cooling mode.	Use minimum heat sources and in a short time.
	Too many people in room in cooling mode.	Reduce temperature settings or change to "Medium" or "High".*

^{*} Fan speed display on the remote controller

High :	35 }}	(CZ-RTC4),	411	(CZ-RTC5B, CZ-RTC6 series)
Medium:	\$6 }	(CZ-RTC4),	41	(CZ-RTC5B, CZ-RTC6 series)
Low :	35	(CZ-RTC4),		(CZ-RTC5B, CZ-RTC6 series)

If your air conditioner still does not work properly although you checked the points as described above, first stop the operation and turn off the power switch. Then contact your dealer and report the serial number and symptom. Never repair your air conditioner by yourself since it is very dangerous for you to do so.

■ Tips for Energy Saving

Avoid

- Do not block the air intake and outlet of the unit. If either is obstructed, the unit will not work well, and may be damaged.
- Do not let direct sunlight into the room. Use sunshades, blinds or curtains. If the walls and ceiling of the room are warmed by the sun, it will take longer to cool the room.

Do

- Always try to keep the air filter clean. (See Section "■ Care and Cleaning".) A clogged filter will impair the performance of the unit.
- To prevent conditioned air from escaping, keep windows, doors and any other openings closed.

NOTE

Should the power fail while the unit is running

If the power supply for this unit is temporarily cut off, the unit will automatically resume operation once power is restored using the same settings before the power was interrupted.

Important Information Regarding The Refrigerant Used

NOTE

Refer to the Installation Instructions attached to the outdoor unit.

12. CHECK OF DENSITY LIMIT


The refrigerant (R32), which is used in the air conditioner, is a flammable refrigerant. So the requirements for installation space of appliance are determined according to the refrigerant charge amount [m_c] used in the appliance.

Regarding the refrigerant charge amount [m_c] used in the appliance, refer to the installation instructions for the outdoor unit.

The minimum indoor floor space compared with the amount of refrigerant is roughly as follows:

Table 12-1

Installation height of Indoor Unit: hinst	Indoor Unit Type	Density Limit Line
hinst ≥ 2.2 m	Duct units (Horizontal installation)	Line 1
1.8 m ≤ hinst < 2.2 m	Duct units (Horizontal installation)	Line 2
hinst < 1.8 m	Duct units (Vertical installation)	Line 3



The minimum indoor floor space compared with the amount of refrigerant is roughly as follows: Use the graph or Table 12-2 to determine the minimum indoor floor space.




Table 12-2

In 11c		[Amin] m ²		
[m₀] kg	Line 1	Line 2	Line 3	
1.22	2.5	3.0	12.8	
1.3	2.6	3.2	14.5	
1.4	2.8	3.4	16.8	
1.5	3.0	3.7	19.3	
1.6	3.2	3.9	22.0	
1.7	3.4	4.2	24.8	
1.8	3.6	4.4	27.8	
1.9	3.8	4.6	31.0	
2.0	4.0	4.9	34.3	
2.1	4.2	5.1	37.8	
2.2	4.4	5.4	41.5	
2.3	4.6	5.6	45.4	
2.4	4.8	5.8	49.4	
2.5	5.0	6.1	53.6	
2.6	5.2	6.5	58.0	
2.7	5.4	7.0	62.6	
2.8	5.6	7.5	67.3	
2.9	5.8	8.1	72.2	
3.0	6.0	8.6	77.2	
3.1	6.2	9.2	82.5	
3.2	6.6	9.8	87.9	
3.3	7.0	10.4	93.4	
3.4	7.4	11.1	99.2	

f 1.1-		[Amin] m ²	
[mc] kg	Line 1	Line 2	Line 3
3.5	7.9	11.7	105.1
3.6	8.3	12.4	111.2
3.7	8.8	13.1	117.5
3.8	9.3	13.8	123.9
3.9	9.8	14.6	130.5
4.0	10.3	15.3	137.3
4.1	10.8	16.1	144.2
4.2	11.3	16.9	151.4
4.3	11.9	17.7	158.7
4.4	12.4	18.5	166.1
4.5	13.0	19.4	173.8
4.6	13.6	20.2	181.6
4.7	14.1	21.1	189.5
4.8	14.8	22.0	197.7
4.9	15.4	22.9	206.0
5.0	16.0	23.9	214.5
5.1	16.7	24.8	223.2
5.2	17.3	25.8	232.0
5.3	18.0	26.8	241.0
5.4	18.7	27.9	250.2
5.5	19.4	28.9	259.6
5.6	20.1	29.9	269.1
5.7	20.8	31.0	278.8

	[Amin] m ²			
[mc] kg	Line 1	Line 2	Line 3	
5.8	21.5	32.1	288.6	
5.9	22.3	33.2	298.7	
6.0	23.0	34.4	308.9	
6.1	23.8	35.5	319.3	
6.2	24.6	36.7	329.8	
6.3	25.4	37.9	340.6	
6.4	26.2	39.1	351.5	
6.5	27.0	40.3	362.5	
6.6	27.9	41.6	373.8	
6.7	28.7	42.8	385.2	
6.8	29.6	44.1	396.8	
6.9	30.4	45.4	408.5	
7.0	31.3	46.8	420.4	
7.1	32.2	48.1	432.5	
7.2	33.1	49.5	444.8	
7.3	34.1	50.9	457.3	
7.4	35.0	52.3	469.9	
7.5	35.9	53.7	482.7	
7.6	36.9	55.1	495.6	
7.7	37.9	56.6	508.7	
7.8	38.9	58.1	522.0	
7.9	39.9	59.6	535.5	

 $m_c \le 1.22$: Can be installed

 $^{1.22 &}lt; m_c \le m_{max}$: Can be installed above "Density Limit Line" *1

^{*1} Refer to Table 12-1 and the installation instructions of indoor unit when deciding "Density Limit Line".

SUPPLEMENT

Contents of Remote Controller Switch Alarm Display

ON: ○ Blinking: ☆ OFF: ●

		Wireless remote controller receiver display				
Abnormal display		Д -()	0	*	Alarm contents	Error location
		Operation	Timer	Standby		
					Faulty remote controller	Replace the remote controller
		Opera blinkin -☆			Disconnection / Contact failure of remote controller wiring CHK (check) pins on the indoor unit control PCB are short circuited	Correct the remote controller wiring Remove the short
	E01		ting lamp g		In the case of non-group control · Power supply OFF of outdoor unit · Disconnection / Contact failure of indoor / outdoor control line * In the case of group control Auto address operation was not carried out	Execute auto address setting
					Faulty setting of EEPROM (IC010) on indoor unit	Replace the indoor unit EEPROM
	E02				Faulty remote controller	Replace the remote controller
					Wrong wiring of remote controller	Correct the remote controller wiring
	E03				Error in indoor unit receiving signal from remote controller (central)	Check the indoor unit control PCB Check the remote controller wiring Check the indoor / outdoor control line *
Remote controller • Indoor Unit			by lam ng ●	amp	Disconnection / Contact failure of indoor / outdoor control line *	Check the electrical connection of indoor / outdoor control line * Replace the indoor unit control PCB Replace the outdoor unit control PCB
	E04	Stand blinkir			Faulty indoor unit control PCB Faulty outdoor unit control PCB Communication circuit fuse (F302) on indoor unit control PCB (sub) opened	Check the electrical connection of fuse (F302) on indoor unit control PCB (sub) In the case of the fuse opened on an indoor unit control PCB (sub), after correcting wiring connection, it substitutes an EMG plug for OC plug
					Fuse on outdoor unit control PCB opened Since failure of an outdoor fan motor is considered as a cause, both outdoor unit control PCB and outdoor unit fan motor are exchanged simultaneously	In the case of the fuse opened on an outdoor unit control PCB, replace both outdoor unit control PCB (CR / HIC) and outdoor unit fan motor simultaneously
ntroller					Setting error of indoor unit address Capacity of indoor / outdoor units is mismatched.	Capacity and address re-setting after correcting the combination of units
SO	E08				Duplication of indoor unit address setting	Indoor unit address re-setting
emote	E09	Opera blinkin	ı. i i		Error because of more than one remote controller setting to main	Correct the setting
ď	E18	*			Disconnection of wiring between main unit and additional units Contact failure of wiring Faulty indoor unit control PCB (main or addition)	Correct the wiring connection Replace the wiring Replace the indoor unit control PCB
	F01	Opera	ting an	p blinking y	Indoor heat exchanger temperature sensor (E1) trouble	Check the indoor unit heat exchanger temperature sensor (E1) Check the indoor unit control PCB
	F02	alterna	ately		Indoor heat exchanger temperature sensor (E2) trouble	Check the indoor unit heat exchanger temperature sensor (E2) Check the indoor unit control PCB
	F10				Indoor air temperature sensor (TA) trouble	Check the indoor unit air temperature sensor (TA) Check the indoor unit control PCB
	F29	timer l	perating and mer lamp blinking multaneously		Indoor unit EEPROM trouble	Check the indoor unit EEPROM Check the indoor unit control PCB
	L02		tina		Setting error, indoor / outdoor unit type / model mismatched	Address re-setting after correcting the combination of units
	L03	Operating and standby			Duplication of main indoor unit address in group control	Correct the group (main and addition)
	L07	simult	amps blinking imultaneously		Group control wiring is connected to individual control indoor unit	Correct the indoor unit address
	L08	*	•	*	Indoor unit address is not set	Correct the indoor unit address
	L09				Indoor unit capacity is not set	Correct the capacity setting of indoor units

* 3-Line : Connection cable between outdoor and indoor unit 2-Line : Inter-unit control wiring

$\mathsf{ON} \colon \bigcirc \quad \mathsf{Blinking} \colon \not \hookrightarrow \quad \mathsf{OFF} \colon \bullet$

Abnormal display		Wireless remote controller receiver display					
		☼∪	(Standby ®	Alarm contents		Error location
		Operation	Timer				
					Indoor unit fa	n motor locked	Remove the cause
	P01				Indoor unit fa	n motor layer short	Replace the fan motor
Remote controller • Indoor Unit					Contact failur	e in thermostat protector circuit	Correct the wiring
	P09	-			Faulty wiring	connections of (ceiling) indoor unit panel	Correct the wiring connection Correct insertion direction of connector (Hook is outside.)
<u>=</u>		Timer stand		, ‡	Faulty drain p	ump	Repair / Replace
er			blinking		Drainage failu	ıre	Correct
tro	P10	altern			Contact failur	e of float switch wiring	Correct the wiring
te con		•	*		High water al duct (PF) mo	arm for the case of Middle static pressure del installed vertically	Change the setting
m D	P11				Faulty drain p	ump	Repair / Replace
Bel	ГП				Drain pump lo	ocked	Remove the cause
	P12					n motor locked connections of indoor unit fan motor	Remove the cause Correct the wiring
			Standby lam		line *	n / Contact failure of indoor / outdoor control	Correct the indoor / outdoor control line * Check the electrical connection of fuse (F302) on indoor unit control PCB (sub)
	E06	blinkir	g •	*		on of indoor / outdoor control line * tion circuit fuse (F302) on indoor unit control pened	In the case of the fuse opened on an indoor unit control PCB (sub), after correcting wiring connection, it substitute an EMG plug for OC plug
					Indoor unit co	ntrol PCB address settings error	Indoor unit address re-setting
	E12	Opera	ating lai	тр	Auto address	setting start is prohibited	Check the indoor / outdoor control line *
	E14	*	• •		Duplication of	main unit in group control	Check the indoor / outdoor control line * Check the indoor unit combination
	E15			qu qu \\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\		The total capacity of indoor units is too low	Check the indoor / outdoor control line *
	E16	Stand blinkir	lby lam		Auto address alarm	The total capacity of indoor units is too high The number of indoor units is too many	Check the indoor and outdoor unit control PCB Check the power supply Capacity and address re-setting after correcting the
	E20		•		L	No indoor unit connected	combination of units
	E24					t communication error	Check the outdoor unit control PCB
	E29				Outdoor uni	t communication error	Check the outdoor unit control PCB
	F04				Compressor	discharge temperature sensor (TD) trouble	Check the compressor discharge temperature sensor (TE Check the outdoor unit control PCB Check the outdoor unit heat exchanger temperature
Unit	F06				Outdoor heat	exchanger temperature sensor (C1) trouble	• Check the outdoor unit rieat exchange temperature sensor (C1) • Check the outdoor unit control PCB
Outdoor U	F07		iting an lamp bl		Outdoor heat	exchanger temperature sensor (C2) trouble	Check the outdoor unit heat exchanger temperature sensor (C2) Check the outdoor unit control PCB
O	F08	altern			Outdoor air te	emperature sensor (TO) trouble	Check the outdoor air temperature sensor (TO) Check the outdoor unit control PCB
	F12	* *	뀨	0	Compressor	suction temperature sensor (TS) trouble	Check the compressor suction temperature sensor (TS) Check the outdoor unit control PCB
	F23				Outdoor gas	pipe temperature sensor trouble	Check the outdoor gas pipe temperature sensor Check the outdoor unit control PCB Check the outdoor liquid pipe temperature sensor
	F24					d pipe temperature sensor trouble	Check the outdoor unit control PCB Check the outdoor unit EEPROM
	F31				Outdoor unit	EEPROM trouble	Check the outdoor unit control PCB Check the oregrant cycle (abnormal overload operation)
	H01		lamp ng		Primary (inpu	t) overcurrent detected	Check the outdoor unit control PCB Check the power supply
	H02	Timer blinkir			PAM trouble		Check the outdoor unit control PCB Compressor locked Check the power supply
	H03		*		Primary curre	nt CT sensor failure	Check the outdoor unit control PCB Check the power supply
	H31				HIC trouble DC voltage no	ot detected	Check the outdoor unit control PCB Check the HIC Compressor locked Valve blockage

^{* 3-}Line : Connection cable between outdoor and indoor unit 2-Line : Inter-unit control wiring

ON: ○ Blinking: ☆ OFF: ●

			ess re	er		
Abnormal		<u>`</u> \$-U ⊕ (*)		*	Alarm contents	Error location
dis	display		Operation			Life location
	L04				Duplication of outdoor unit address	Check the indoor / outdoor control line *
	L10	and standby		i	Outdoor unit capacity is not set or setting error	Replace the outdoor unit EEPROM Capacity value re-setting
	L13			sĬy	Indoor unit type setting error Type of indoor / outdoor units is different	Replace the indoor unit EEPROM Check the outdoor unit control PCB Check the type of IU and OU, and re-set address
	L18	 	0	ఘ	4-way valve locked trouble / operation failure	Check the 4-way valve Check the 4-way valve wiring Check the outdoor unit control PCB
	P03	Opera			Compressor discharge temperature trouble	Check the refrigerant cycle (gas leak) Trouble with the electronic expansion valve Check the discharge temperature sensor (TD)
	P04		standby blinking		Condensing pressure trouble Compressor discharge pressure trouble	Check the refrigerant cycle Valve blockage Heat exchanger obstruction
	P05	lamp l altern		; ☆	Open phase detected AC power supply trouble	Check the power supply Check the reactor wiring Check the outdoor unit control PCB Check the compressor wiring
Outdoor Unit	P07	7			HIC (IPM) temperature trouble	Check the outdoor unit control PCB Check the HIC Compressor locked Valve blockage
Outc	P13	Timer and standby lamp blinking			Valve error Refrigerant circuit error Wrong installation for refrigerant piping and wiring	Valve blockage Check the refrigerant circuit Check the refrigerant piping and wiring installation
	P14	altern	ately :	*	O ₂ sensor detected	• Input from the O2 sensor
	P15				Insufficient gas level detected	Check the refrigerant cycle (gas leak) Trouble with the electronic expansion valve Valve (or refrigerant circuit) blockage
	P16	Opera			Compressor overcurrent trouble	Layer short on the compressor Compressor locked Check the outdoor unit control PCB
	P22		tandby blinking ately		Outdoor unit fan motor trouble Outdoor unit fan trouble	Check the outdoor unit fan motor, connector Check the outdoor unit control PCB
	P29	☆ •		, ‡	Inverter compressor trouble	Layer short on the compressor Check the outdoor unit control PCB Check the inverter compressor wiring (Open phase / Reverse phase) Compressor actuation failure (include lock) Valve (or refrigerant circuit) blockage
	P31				Indoor unit in group control trouble	Repair indoor unit which blinking alarm

^{* 3-}Line : Connection cable between outdoor and indoor unit 2-Line : Inter-unit control wiring